TIME		DAY	DATE	[illegible]	TIME	
	2400	WED.	26	START SKIMMING MB 23 AT (0300 HRS)	0000	0400
	0400		26	STOPPED SKIMMING M.B. 23 AT 0900 HRS AND CHANGED OVER TO M.B. 22 (6 HRS)	0800	1200
	2400		26	STOPPED SKIMMING MB 22 AT 1500 HRS. AND CHANGED OVER TO MB 23 (6 HRS.)	1200	1600
	2400		26	CHANGED BURNERS M.B 22	2000	2400
	0400		26	STOPPED SKIMMING M.B. 23 AT 2100 HRS AND CHANGED OVER TO M.B. 22 (6 HRS)	2000	2400
	1200	THU.	27	STOP SKIMMING MB 22 AT (0015 HRS.)	0000	0400
	2000		27	BLOW SOOT MB 22 & 23	0000	0400
	2400		27	START FIRING M.B. 21 AT 0950 HRS	0800	1200
	0400		27	ON LINE MB 21 AT. 1840 HRS	1600	2000
	2400		27	CHANGED BURNERS M.B. 23	2000	2400
	0400	FRI.	28	BLOW SOOT MB 21 & 22, 23	0000	0400
	0400		28	SKIMMING MB 23 AT (0330 HRS.) 6 HRS.	0000	0400
	1200		28	STOPPED SKIMMING M.B. 23 AT 0930 HRS AND CHANGED OVER TO M.B. 22 (6 HRS)	0800	1200
	1200		28	STOP SKIMMING MB 22 AT 1530 HRS. AND CHANGED OVER TO MB 23 (6 HRS.)	1200	1600
	2400		28	CHANGED BURNER'S M.B. 22	2000	2400
	0400		28	STOPPED SKIMMING M.B. 23 AT 2130 HRS AND CHANGED OVER TO M.B. 22 (6 HRS)	2000	2400
	2000	SAT.	29	BLOW SOOT MB 21, 22 & 23	0000	0400
	2400		29	CLOCK RETARD 1 HR AT 0200 HRS.	0000	0400
	0400		29	STOP SKIMMING MB 22 AT 0330 HRS AND CHANGED OVER TO MB 23 (6 HRS)	0000	0400
	0400		29	STOPPED SKIMMING M.B. 23 AT 0930 HRS AND CHANGED OVER TO M.B. 22 (6 HRS)	0800	1200
	0800		29	OFF LINE M.B. 23 AT 0950 HRS	0800	1200
	1600		29	BOTTOM BLOW DOWN M.B. 23 15 MINS.	0800	1200
	1600		29	STOP SKIMMING M.B. 22 AT 2000 HRS	1600	2000
	2000		29	CHANGED BURNERS M.B. 21	2000	2400
	2400	SUN.	30	BLOW SOOT MB 21 & 22	0000	0400
	0400		30	CHANGED BURNERS M.B. 22	2000	2400
	0400	MON.	31	BLOW SOOT MB 21 & 22	0000	0400
	0400		31	CLOCK ADVANCE (1 HOUR) AT 0200 HRS	0000	0400
	0800		31	CHANGED BURNERS M.B. 21	2000	2400
	1600		*	HAPPY NEW YEAR	*	
	2000	2002		S/S NORWAY	2002	
	2400					
	0400		*	JANUARY 2002		*
	0400	THE	01	BLOW SOOT MB 21 & 22	0000	0400
			01	CHANGED BURNER'S MB 22	2000	2400

MC LON

January 2002

DAY	DATE		TIME		DAY	DATE
WED.	02	BLOW SOOT MB. 21 & 22	0000	0400	FRI.	11
	02	CHANGED BURNERS M.B. 21	2000	2400		11
		[redacted]				11
THU.	03	BLOW SOOT MB 21 & 22	0000	0400		11
	03	START FIRING M.B. 23 AT 11.00 HRS	0800	1200		11
	03	ON LINE MB 23 AT 1820 Hrs	1600	2000	SAT.	12
	03	CHANGED BURNERS M.B. 22	2000	2400		12
FRI.	04	BLOW SOOT MB 21, 22 & 23	0000	0400		12
	04	START SKIMMING MB. 23 AT 1700 Hrs (6 Hrs)	1600	2000		12
	04	CHANGED BURNERS M.B. 21	2000	2400		12
	04	STOPPED SKIMMING M.B. 23 AT 2300 HRS	2000	2400		12
SAT.	05	BLOW SOOT MB 21, 22 & 23	0000	0400		12
	05	CLOCK RETARD 1 HR AT 0200 HRS.	0000	0400	SUN.	13
	05	OFF LINE M.B. 23 AT 1010 HRS	0800	1200		13
	05	BOTTOM BLOW DOWN M.B. 23 (15 MINS.)	0800	1200	MON	14
OMOLON	05	START SKIMMING MB 21 AT 1700 HRS (6 HRS)	1600	2000		14
	05	CHANGED BURNERS M.B. 22	2000	2400		14
	05	STOPPED SKIMMING M.B. 21 AT 2300 HRS	2000	2400		14
SUN.	06	BLOW SOOT MB 21 & 22	0000	0400		14
	06	CHANGED BURNERS M.B. 21	2000	2400		14
MON.	07	BLOW SOOT MB. 21 & 22	0000	0400	TUE	15
	07	START SKIMMING MB 22 AT (1330 HRS) 6 HRS	1200	1600		15
	07	STOPPED SKIMMING MB#22 AT 1930 HRS	1600	2000		15
	07	CHANGED BURNERS M.B. 22	2000	2400		15
TUE.	08	BLOW SOOT MB 21 & 22	0000	0400		15
	08	CLOCK ADVANCE 1 HRS AT 0200 HRS.	0000	0400	WED	16
	08	CHANGED BURNERS M.B. 21	2000	2400		16
WED.	09	BLOW SOOT MB 21 & 22	0000	0400		16
	09	CHANGED BURNERS M.B. 22	2000	2400	THU.	17
THU.	10	BLOW SOOT MB 21 & 22	0000	0400		17
	10	START FIRING M.B. 23 AT 0800	0800	1200	FRI	18
	10	ON LINE BOILER #23 AT 1300 HRS	1600	2000		18
	10	CHANGED BURNERS M.B. 21	2000	2400		18
FRI.	11	BLOW SOOT MB 21, 22 & 23	0000	0400		18

TIME		DAY	DATE		TIME	
0000	0400	FRI.	11	START SKIMMING MB 22 AT (1500 HRS.) 6 HRS	1200	1600
2000	2400		11	STOPPED SKIMMING MB#22 AT (2000 HRS)	1600	2000
~~2000~~	~~2400~~		11	START SKIMMING MB#21 AT (2000 HRS) 4 HRS	1600	2000
0000	0400		11	CHANGED BURNERS M.B. 22	2000	2400
0800	1200		11	STOPPED SKIMMING M.B. 21 AT 2400 HRS	2000	2400
1600	2000	SAT.	12	BLOW SOOT MB 21, 22 & 23	0000	0400
2000	2400		12	CLOCK RETARD 1 HR AT 0200 HRS.	0000	0400
0000	0400		12	START SKIMMING MB 22 AT (0200 HRS.) 6 HRS.	0000	0400
1600	2000		12	OFF LINE M.B. 21 AT 0930 HRS	0800	1200
2000	2400		12	BOTTOM BLOW DOWN M.B. 21 (15 MINS.)	0800	1200
2000	2400		12	~~START SKIMMING MB 23 AT (1500 HRS.) 6 HRS.~~	~~1200~~	~~1600~~
0000	0400		12	CHANGED BURNERS M.B. 23	2000	2400
0000	0400	SUN.	13	BLOW SOOT MB. 22 & 23	0000	0400
0800	1200		13	CHANGED BURNERS MB. 22	2000	2400
0800	1200	MON	14	BLOW SOOT M.B. 22 & 23	0000	0400
1600	2000		14	START SKIMMING MB 23 AT (0400 HRS.) 6 HRS.	0400	0800
2000	2400		14	STOPPED SKIMMING MB 23 AT (1000 HRS)	0800	1200
2000	2400		14	START SKIMMING MB 23 AT (1700 HRS.) 7 HRS	1600	2000
0000	0400		14	STOPPED SKIMMING MB. 23 AT (2400 HRS)	2000	2400
2000	2400		14	CHANGED BURNERS MB. 23	2000	2400
0000	0400	TUE	15	BLOW SOOT M.B. 22 & 23	0000	0400
1200	1600		15	START FIRING M.B. 24 AT 1450 HRS	1200	1600
1600	2000		15	ON LINE BOILER #24 AT 2000 HRS	2000	2400
2000	2400		15	OFF LINE BOILER #24 AT 2300 HRS	2000	2400
0000	0400		15	START FIRING BOILER #21 AT 2330 HRS	2000	2400
0000	0400	WED	16	CHANGED BURNERS BLR #22 BLOW SOOT M.B. 22 & 23	0000	0400
2000	2400		16	ON LINE MB. 21 AT 0530 HRS.	0400	0800
0000	0400		16	CHANGED BURNERS MB. 23	2000	2400
2000	2400	THU.	17	BLOW SOOT M.B. 21, 22 & 23	0000	0400
0000	0400		17	CHANGED BURNERS MB. 21	2000	2400
0800	1200	FRI	18	BLOW SOOT M.B. 21, 22 & 23	0000	0400
1600	2000		18	START SKIMMING M.B. 23 AT 0100 HRS (6 HRS)	0000	0400
2000	2400		18	STOPPED SKIMMING MB. 23 AT 0700 HRS.	0400	0800
0000	0400		18	START SKIMMING MB. 23 AT 1700 HRS (10 HRS)	1600	2000

DAY	DATE		TIME		DAY	DATE
FRI.	18	CHANGED BURNERS MB-22	2000	2400	FRI.	25
SAT.	19	STOP SKIMMING MB. 23 AT 00:15 HRS.	0000	0400	SAT.	26
	19	NO BLOW SOOT (ALL 21, 22 & 23 BOILERS SHUT DOWN)	0000	0400		26
	19	START SKIMMING M.B. 23 AT 1400 HRS (6 HRS)	0000	0400		26
	19	OFF LINE MB. 21 AT (1610 HRS.)	1600	2000		26
	19	BOTTOM BLOW DOWN (15 MIN.) MB. 21	1600	2000		26.
	19	STOPPED SKIMMING MB 23 AT (2000 HRS) & CHANGED OVER TO MB 22 (6 HRS.)	1600	2000		26
	19	CHANGED BURNERS MB-23	2000	2400		26
SUN.	20	BLOW SOOT M.B. 21, 22 & 23	0000	0400		26
	20	STOPPED SKIMMING M.B. 22 AT 0200 HRS	0000	0400	SUN.	27
	20	CHANGED BURNERS MB-22	2000	2400		27
MON	21	BLOW SOOT M.B. 22 & 23	0000	0400		27
	21	START SKIMMING M.B. 23 AT 0350 (5 HRS)	0000	0400		27
	21	START FIRING MB-21 AT 0800	0800	1200		27
	21	ON LINE MB 21 AT (1605 HRS.)	1600	2000	MON.	28
	21	STOPPED SKIMMING MB. 22 AT 2000 HRS AND CHANGED OVER TO MB. 23 (8 HRS.)	2000	2400		28
	21	CHANGED BURNERS MB-23	2000	2400		28
TUE	22	BLOW SOOT M.B. 21, 22 & 23	0000	0400		28
	22	CONTINUE SKIMMING M.B. 23 AT 0400 (10 HRS)	0000	0400		28
	22	STOPPED SKIMMING M.B. 23 AT 1400 HRS AND CHANGED OVER TO M.B. 21 (8 HRS)	1200	1600		28
	22	CHANGED BURNERS MB-22	2000	2400		28
	22	STOPPED SKIMMING M.B. 21 AT 2200 HRS AND CHANGED OVER TO M.B. 23 (10 HRS)	2000	2400	TUE.	29
WED	23	BLOW SOOT M.B. 21, 22 & 23	0000	0400		29
	23	STOPPED SKIMMING MB. 23 AT 0800 HRS. AND CHANGED OVER TO MB 22 (10 HRS.)	0400	0800		29
	23	STOPPED SKIMMING M.B. 22 AT 1400 HRS AND CHANGED OVER TO M.B. 23 (6 HRS)	1200	1600		29
	23	STOPPED SKIMMING MB 23 AT (2000 HRS.)	1600	2000		29
	23	CHANGED BURNERS MB-21	2000	2400		29
THU.	24	BLOW SOOT M.B. 21, 22 & 23	0000	0400	WED.	30
	24	START SKIMMING M.B. 23 AT 0300 HRS (6 HRS)	0000	0400		30
	24	STOPPED SKIMMING MB-23 AT 0900 HRS	0800	1200		30
	24	CHANGED BURNERS MB-23	2000	2400	THU.	31
FRI.	25	BLOW SOOT M.B. 21, 22 & 23	0000	0400		31
	25	START SKIMMING M.B. 23 AT 1400 HRS (8 HRS)	1200	1600		
	25	CHANGED BURNERS MB-22	2000	2400		

TIME		DAY	DATE		TIME	
0	2400	FRI.	25	STOPPED SKIMMING MB-23 AT 2200 HRS	2000	2400
0	0400	SAT.	26	BLOW SOOT M.B. 21, 22 & 23	0000	0400
0	0400		26	START SKIMMING M.B. 23 AT 0000 hrs (12 hrs)	0000	0400
0	0400		26	STOPPED SKIMMING MB-23 AT 1130 HRS.	0800	1200
0	2000		26	START SKIMMING M.B. 22 AT 1200 hrs (8 hrs)	1200	1600
0	2000		26.	OFF LINE MB 23 AT 1915 HRS	1600	2000
0	2000		26	BOTTOM BLOW DOWN MB. 23 (15 MINS.)	1600	2000
0	2400		26	STOPPED SKIMMING MB ~~23~~ AT 2000 HRS. AND CHANGED OVER TO MB. 21 6 HRS.	1600	2000
0	0400		26	CHANGED BURNERS MB-21	2000	2400
0	0400	SUN.	27	BLOW SOOT M.B. 21 & 22	0000	0400
0	2400		27.	STOPPED SKIMMING M.B. 21 AT 0200 HRS	0000	0400
0	0400		27	START SKIMMING M.B. 22 AT 1800 HRS.	1600	2000
0	0400		27	CHANGED BURNERS MB-22	2000	2400
0	1200		27	START FIRING MB-23 AT 2200 HRS	2000	2400
0	2000	MON.	28	BLOW SOOT M.B. 21 & 22	0000	0400
0	2400		28	STOPPED SKIMMING M.B. 22 AT 0400 HRS AND CHANGED OVER TO M.B. 21	0000	0400
0	2400		28	STOPPED SKIMMING M.B. 21 AT 04:20 HRS	0400	0800
0	0400		28	ON LINE MB-23 AT 0830	0800	1200
0	0400		28	ON LINE M.B. 24 AT 2010	2000	2400
0	1600		28	CHANGED BURNERS MB-21	2000	2400
0	2400		28	OFF LINE MB-21 AT 2200 HRS	2000	2400
0	2400	TUE.	29	BLOW SOOT ~~M.B. 21, 23 & 24~~	0000	0400
0	0400		29	START SLOW FIRING M.B. 22. 06:00 HRS.	0400	0800
0	0800		29	ON LINE MB-22 AT 1000	0800	1200
0	1600		29	OFF LINE MB-24 AT 1020	0800	1200
0	2000		29	START SLOW FIRING M.B. 21 AT 17:25 HRS	1600	2000
0	2400		29	ON LINE M.B. 21 AT 2400 HRS	2000	2400
0	0400	WED.	30	BLOW SOOT M.B. 21, 22 & 23	0000	0400
0	0400		30	STOPPED SKIMMING M.B. 23. 18:30 HRS.	1600	2000
0	2000		30	CHANGED BURNERS MB-23	2000	2400
0	2400	THU.	31	BLOW SOOT M.B. 21, 22 & 23	0000	0400
0	0400		31	CHANGED BURNERS MB-22	2000	2400
0	1600					
0	2400					

February 2002

DAY	DATE		TIME		DAY	DATE
FRI.	01	BLOW SOOT M.B. 21, 22 & 23	0000	0400	MON-	11
	01	CHANGED BURNERS MB-23	2000	2400		11
SAT.	02	BLOW SOOT M.B. 21, 22 & 23	0000	0400		11
	02	STOPPED SKIMMING M.B. 22 AT 04:45 HRS.	0400	0800		11
	02	OFF LINE MB-21 AT 1135	0800	1200		11
	02	START SKIMMING M.B. 22 AT 0115 HRS	1200	1600		11
	02	STOPPED SKIMMING M.B. 22 AT 1900 HRS.	1600	2000	TUE-	12
	02	CHANGED BURNERS MB-22	2000	2400		12
SUN.	03	BLOW SOOT M.B. 22 & 23	0000	0400		12
	03	CHANGED BURNERS MB-23	2000	2400		12
MON.	04	BLOW SOOT M.B. 22 & 23	0000	0400	WED-	12
	04	START SKIMMING M.B. 23 AT 0015 hrs	0000	0400		13
	04	STOPPED SKIMMING M.B. 23 AT 19:40 HRS.	1600	2000		13
	04	CHANGED BURNERS MB-22	2000	2400		13
TUE	05	BLOW SOOT M.B. 22 & 23	0000	0400	THU-	14
	05	START SKIMMING M.B. 23 AT 0030 hrs	0000	0400		14
	05	CHANGED BURNERS MB-23	2000	2400		14
WED.	06	BLOW SOOT M.B. 22 & 23	0000	0400		14
	06	STOPPED SKIMMING M.B 23 AT 1310 hrs	1200	1600	FRI-	15
	06	CHANGED BURNERS MB-22	2000	2400		15
THU.	07	BLOW SOOT M.B. 22 & 23	0000	0400		15
	07	START FIRING MB-21 0900 HRS	0800	1200	SAT-	16
	07	ON LINE M.B. 21 AT 17:35 HRS.	1600	2000		16
	07	CHANGED BURNERS MB-23	2000	2400		16
FRI.	08	BLOW SOOT M.B. 21, 22 & 23	0000	0400	SUN-	17
	08	START SKIMMING M.B. 21 AT 0010 HRS	0000	0400		17
	08	STOPPED SKIMMING M.B. 21 AT 1215 HRS AND CHANGED OVER TO M.B. 22	1200	1600		17
	08	STOPPED SKIMMING M.B. 22 AT 2000 HRS CHANGED OVER M.B. 23	1600	2000	MON-	18
SAT.	09	BLOW SOOT M.B. 21, 22 & 23	0000	0400		18
	09	STOPPED SKIMMING MB-23 AT 0900	0800	1200		18
	09	OFF LINE MB-23 AT 1000	0800	1200		18
	09	CHANGED BURNERS MB-21	2000	2400		18
SUN.	10	BLOW SOOT M.B. 21 & 22	0000	0400		18
	10	CHANGED BURNERS M.B. 22	2000	2400		18

TIME	DAY	DATE		TIME	
0400	MON-	11	BLOW SOOT MB-21 & 22	2400	0400
2400		11	START SLOW FIRING M.B. 24 AT 08:45 HRS	0800	1200
0400		11	ON LINE M.B. 24 20:10 HRS.	2000	2400
0800		11	CHANGED BURNERS M.B. 21.	2000	2400
1200		11	OFF LINE M.B. 24 AT 22:35 HRS.	2000	2400
1600		11	START SLOW FIRING M.B. 23 AT 23:40 HRS	2000	2400
2000	TUE-	12	BLOW SOOT MB-21 & 22	2400	0400
2400		12	ON LINE M.B. 23 AT 09:20 HRS.	0800	1200
0400		12	START SKIMMING AT MB-23 AT 16 HRS	1600	2000
2400		12	CHANGED BURNERS M.B. 22.	2000	2400
0400	WED-	13	BLOW SOOT MB-21-22-23	2400	0400
0400		13	STOPPED SKIMMING M.B. 23 AT 08:35 HRS	0800	1200
2000		13	START SKIMMING M.B. 23 AT 1945 HRS	1600	2000
2400		13	CHANGED BURNERS M.B. 21 @	2000	2400
0400	THU-	14	BLOW SOOT MB-21-22-23	2400	0400
0400		14	STOPPED SKIMMING M.B. 23 AT 0500 HRS	0400	0800
2400		14	START SKIMMING M.B. 23 AT 1930 HRS	1600	2000
0400		14	CHANGED BURNERS M.B. 23 @	2000	2400
0400	FRI-	15	BLOW SOOT MB-21-22-23	2400	0400
2400		15	STOPPED SKIMMING MB-23 AT 1300 HRS	1200	1600
0400		15	CHANGED BURNERS M.B. 22. @	2000	2400
1200	SAT-	16	BLOW SOOT MB-21-22-23	2400	0400
2000		16	SKIMMING MB 23 AT 1830 HRS.	1600	2000
2400		16	CHANGED BURNERS M.B. 21 @	2000	2400
0400	SUN-	17	BLOW SOOT MB-21-22-23	2400	0400
0400		17	STOPPED SKIMMING MB-23 AT 0300	2400	0400
1600		17	CHANGED BURNERS M.B. 23 @	2000	2400
2000	MON-	18	START SLOW FIRING MB-24 AT 2420 HRS	2400	0400
0400		18	BLOW SOOT MB-21-22-23	2400	0400
1200		18	START SKIMMING M.B. 21 AT 05'5H. (6H)	0400	0800
1200		18	STOPPED SKIMMING M.B. 21 AT 11:15 HRS. CHANGED OVER M.B. 22.	0800	1200
2400		18	ON LINE MB-24 1200 HRS	1200	1600
0400		18	STOPPED SKIMMING M.B. 22 AT 1600 HRS	1600	2000
2400		18	OFF LINE M.B. 24 AT 1630 HRS	1600	2000

VALENZUELA - 12-4
OMOLON F. - 4-8
SUMAYLO C. - 8-12

DAY	DATE		TIME		DAY	DAT
MON	18	CHANGED BURNERS M.B. 22 @	2000	2400	FRI-	01
TUE-	19	BLOW SOOT MB-21-22-23	2400	0400		01
	19	CHANGED BURNERS M.B. 21 @	2000	2400	SAT-	02
WED-	20	BLOW SOOT MB-21-22-23	2400	0400		02
	20	START SKIMMING M.B. 21 AT 1600 HRS. (6H)	1600	2000	SUN-	02
	20	CHANGED BURNERS M.B. 23 @	2000	2400	SUMAYLO START	03
	20	STOPPED SKIMMING M.B. 21 AT 22:00 HRS. CHANGED OVER TO M.B. 22.	2000	2400	MON-	04
THU-	21	BLOW SOOT MB-21-22-23	2400	0400		04
	21	STOPPED SKIMMING M.B. 22 AT 0200 HRS- CHANGED OVER TO M.B. 23	2400	0400		04
	22	STOPPED SKIMMING M.B. 23 AT 0530 HRS.	0400	0800	TUE-	05
	22	CHANGED BURNERS M.B. 22 @	2000	2400	CODE OSCAR	05
FRI-	22	BLOW SOOT MB-21-22-23	2400	0400		05
	22	CHANGED BURNERS M.B. 21 @	2000	2400	WED-	06
SAT-	23	BLOW SOOT MB-21-22-23	2400	0400	*	06
	23	START SKIMMING M.B. 23 AT 1940 HRS	1600	2000	THU-	07
	23	CHANGED BURNERS M.B. 23 @	2000	2400		07
SUN-	24	BLOW SOOT MB-21-22-23	2400	0400	FRI-	08
	24	STOPPED SKIMMING MB-23 AT 0300 HRS.	2400	0400		08
	24	CHANGED BURNERS M.B. 22 @	2000	2400	SAT-	09
MON-	25	OFF LINE MB-22 AT 2400 HRS	2400	0400		09
	25	BLOW SOOT MB-21-23	2400	0400	SUN-	10
	25	CHANGED BURNERS M.B. 21 @	2000	2400	CREW CHECK *	10
TUE-	26	BLOW SOOT MB-21-23	2400	0400	MON.	11
	26	CHANGED BURNERS M.B. 23 @	2000	2400		11
WED-	27	BLOW SOOT MB-21-23	2400	0400	TUE.	12
	27	START SKIMMING M.B. 23 AT 1930 HRS	1600	2000		12
	27	CHANGED BURNERS M.B. 21 @	2000	2400	WED.	13
THU-	28	BLOW SOOT MB-21-23	2400	0400		13
	28	START FILING MB-22 AT 0100 HRS STOPPED SKIMMING MB-23 AT 0320 HRS	2400	0400		13
	28	ON-LINE M.B. 22 AT 1800 HRS	1600	2000	THU.	14
	28	CHANGED BURNERS M.B. 23 @	2000	2400		14
						14
					FRI.	15

MARCH * 2002

TIME		DAY	DATE		TIME	
00	2400	FRI-	01	BLOW SOOT MB-21-22-23	2400	0400
00	0400		01	CHANGED BURNERS M.B. 21 @	2000	2400
00	2400	SAT-	02	BLOW SOOT MB-21-22-23	2400	0400
00	0400		02	CHANGED BURNERS M.B. 22 @	2000	2400
00	2000	SUN-	03	BLOW SOOT MB-21-22-23	2400	0400
00	2400	SUMAYLO START	03	CHANGED BURNERS M.B. 23 @	2000	2400
00	2400	MON-	04	BLOW SOOT MB-21-22-23	2400	0400
00	0400		04	START SKIMMING MB.23 AT (1800 HRS.) 8 HRS.	1600	2000
00	0400		04	CHANGED BURNERS M.B. 21 @	2000	2400
400	0800	TUE-	05	BLOW SOOT MB-21-22-23	2400	0400
00	2400	CODE OSCAR	05	STOPPED SKIMMING MB-23 AT 0200	2400	0400
00	0400		05	CHANGED BURNERS M.B. 22 @	2000	2400
00	2400	WED-	06	BLOW SOOT MB-21-22-23	2400	0400
00	0400		06	CHANGED BURNERS M.B. 23 @	2000	2400
00	2000	THU-	07	BLOW SOOT MB-21-22-23	2400	0400
00	2400		07	CHANGED BURNERS M.B. 21 @	2000	2400
00	0400	FRI-	08	BLOW SOOT MB-21-22-23	2400	0400
00	0400		08	CHANGED BURNERS M.B. 22 @	2000	2400
00	2400	SAT-	09	BLOW SOOT MB-21-22-23	2400	0400
00	0400		09	CHANGED BURNERS M.B. 23 @	2000	2400
00	0400	SUN-	10	BLOW SOOT MB-21-22-23	2400	0400
00	2400	CREW CHECK *	10	CHANGED BURNERS MB. 21	2000	2400
00	0400	MON.	11	BLOW SOOT M.B. 21, 22, & 23 @	0000	0400
00	2400		11	CHANGED BURNERS M.B. 22	2000	2400
00	0400	TUE.	12	BLOW SOOT M.B. 21, 22, & 23 @	0000	0400
00	2000		12	CHANGED BURNERS M.B. 23	2000	2400
00	2400	WED.	13	BLOW SOOT M.B. 21-22-23 @	0000	0400
00	0400		13	BOTTOM BLOW DOWN MB. 21, 22, 23 AT (0900)	0800	1200
00	0400		13	CHANGED BURNERS M.B. 21	2000	2400
00	2000	THU.	14	BLOW SOOT M.B. 21-22-23 @	0000	0400
00	2400		14	ON LINE MB-23 AT 1950 HRS	1600	2000
			14	CHANGED BURNERS M.B. 22	2000	2400
		FRI.	15	BLOW SOOT M.B. 21-22-23	0000	0400

DAY	DATE		TIME	
FRI.	15	CHANGED BURNERS M.B. 23	2000	2400
SAT.	16	BLOW SOOT M.B. 21, -22, -23 @	0000	0400
	16	START SKIMMING M.B 21 AT 2000 HRS (2 HRS.)	2000	2400
	16	CHANGED BURNERS M.B. 21	2000	2400
	16	STOPPED SKIMMING M.B 21 AND CHANGED OVER TO M.B. 22 AT (2200 HRS.) (2 HRS.)	2000	2400
	16	STOPPED SKIMMING M.B. 22 AND CHANGED OVER TO M.B. 23 AT (2400 HRS.) (3 HRS.)	2000	2400
SUN.	17	BLOW SOOT M.B. 21 - 22 - 23 @	0000	0400
	17	STOPPED SKIMMING M.B. 23 AT. 0300 HRS.	0000	0400
	17	CHANGED BURNERS M.B. 22	2000	2400
MON.	18	BLOW SOOT M.B. 21 - 22 - 23 @	0000	0400
	18	CHANGED BURNERS M.B. 23	2000	2400
TUE.	19	BLOW SOOT M.B. 21 - 22 - 23 @	0000	0400
	19	CHANGED BURNERS M.B. 21	2000	2400
WED.	20	BLOW SOOT M.B. 21 - 22 - 23 @	0000	0400
	20	CHANGED BURNERS M.B. 22	2000	2400
THU.	21	BLOW SOOT M.B. 21 - 22 - 23 @	0000	0400
	21	CHANGED BURNERS M.B. 23	2000	2400
FRI.	22	BLOW SOOT M.B. 21 - 22 - 23 @	0000	0400
	22	CHANGED BURNERS M.B. 21	2000	2400
SAT.	23	BLOW SOOT M.B. 21 - 22 - 23 @	0000	0400
	23	CLOCK RETARDED 1 HR. AT. 02:00 HRS.	0000	0400
	23	OFF LINE M.B. 21 AT (1100 HRS.)	0800	1200
	23	BOTTOM BLOW DOWN 15 MIN. M.B. 21	0800	1200
	23	START SKIMMING M.B. 22 AT (2030 HRS.)	2000	2400
	23	CHANGED BURNERS M.B. 22	2000	2400
	23	STOPPED SKIMMING M.B 22 AT (2300 HRS.) AND CHANGED OVER TO M.B 23	2000	2400
SUN.	24	BLOW SOOT M.B. 22 - 23 @	0000	0400
	24	STOPPED SKIMMING M.B. 23 AT 02:00 HRS.	0000	0400
	24	CHANGED BURNERS M.B. 23	2000	2400
MON.	25	BLOW SOOT M.B. 22 = 23 @	0000	0400
	25	START SLOW FIRING AT 1945 HRS.	1600	2000
	25	CHANGED BURNERS M.B. 22	2000	2400
TUE.	26	BLOW SOOT M.B. 22 - 23 @	0000	0400

DAY	DATE
TUE.	26
	26
	26
	26
	26
	26
WED.	27
	27
	27
	27
THU.	28
HOLY	28
FRI.	29
HOLY	29
SAT.	30
*	30
	30
	30
	30
SUN.	31
	31
MON.	01
	01
TUE.	02
	02
	02
	02
	02
WED.	03
	03
	03
	03

TIME		DAY	DATE		TIME	
00	2400	TUE.	26.	ON LINE MB#24 AT 0600	0400	0800
00	0400		26	OFF LINE MB #24 AT 0800	0800	1200
00	2400		26	START SLOW FIRING M.B. 21 AT (1000 HRS)	0800	1200
00	2400		26	ON LINE MB#21 AT 1630	1600	2000
00	2400		26	START SKIMMING M.B. 22 AT (2030 HRS)	2000	2400
00	2400		26	CHANGED BURNERS M.B. 23	2000	2400
00	0400	WED.	27.	SOOT BLOW M.B. 21-22-23 @	0000	0400
00	0400		27	STOPPED SKIMMING M.B. 22 AT 01:30 HRS CHANGED OVER M.B. 23. (6 HRS)	0000	0400
00	2400		27	STOPPED SKIMMING MB-23 AT 0700 HRS	0400	0800
00	0400		27	CHANGED BURNERS M.B. 21	2000	2400
00	2400	THU.	28	SOOT BLOW M.B. 21-22-23 @	0000	0400
00	0400	HOLY	28	CHANGED BURNERS M.B. 22	2000	2400
00	2400	FRI.	29	BLOW SOOT M.B. 21-22-23 @	0000	0400
00	0400	HOLY	29	CHANGED BURNERS. M.B. 23	2000	2400
00	2400	SAT.	30	BLOW SOOT M.B. 21=22=23 @	0000	0400
00	0400	*	30	CLOCK RETARDED (1 HR.) AT 02:00 HRS.	0000	0400
00	2400		30	OFF LINE M.B #21 AT (1050 HRS)	0800	1200
00	0400		30	BOTTOM BLOW DOWN (15 MIN.) M.B. #21	0800	1200
00	2400		30	CHANGED BURNER'S M.B. 22	2000	2400
00	0400	SUN.	31	BLOW SOOT M.B. 22=23 @	0000	0400
00	0400		31	CHANGED BURNER'S M.B. 23	2000	2400
00	1200			* APRIL 2002 *		
00	1200	MON.	01	BLOW SOOT M.B. 22 = 23 @	0000	0400
00	2400		01	CHANGED BURNER'S M.B. 22	2000	2400
00	2400	TUE.	02	BLOW SOOT M.B. 22 = 23 @	0000	0400
00	2400		02	START SLOW FIRING M.B. 21 AT 0910 HRS.	0800	1200
00	0400		02	ON LINE M.B. 21 AT 16:10 HRS.	1600	2000
00	0400		02	CHANGED BURNER'S M.B. 23	2000	2400
00	2400		02	START SKIMMING M.B. 23 AT 2120 HRS. (6-HRS)	2000	2400
00	0400	WED.	03	BLOW SOOT M.B. 21-22-23	0000	0400
00	2000		03	STOPPED SKIMMING M.B. 23 AT 03:20 HRS.	0000	0400
00	2400		03	CHANGE BURNER'S M.B. 22	2000	2400
00	0400		03	START SKIMMING M.B. 21 AT 2115 HRS. (6-HRS)	2000	2400

APRIL 2002

DAY	DATE		TIME	
THU.	04	BLOW SOOT M.B. 21 = 22 = 23 @	0000	0400
	04	STOPPED SKIMMING M.B-22 AT. 03:15 HRS	0000	0400
	04	CHANGED BURNER'S M.B. 21	2000	2400
	04	START SKIMMING M.B. 21 AT 2230 Hrs.	2000	2400
FRI.	05	BLOW SOOT M.B. 21 = 22 = 23 @	0000	0400
	05	STOPPED SKIMMING MB-21 AT 0430	0400	0800
	05	CHANGED BURNER'S M.B. 23	2000	2400
SAT.	06	BLOW SOOT M.B. 21 = 22 = 23 @	0000	0400
	06	OFF LINE M.B. 21 AT = 11:45 HRS.	0800	1200
	06	CHANGED BURNER'S M.B. 22	2000	2400
SUN.	07	BLOW SOOT M.B. 22 = 23 @	0000	0400
SUN.	07	CHANGED BURNER'S MB-23	2000	2400
MON.	08	BLOW SOOT M.B. 22 & 23	0000	0400
	08	START SLOW FIRING MB-24 0820	0800	1200
	08	ON LINE M.B. 24 AT = 19:50 HRS.	1600	2000
	08	CHANGED BURNER'S MB-22	2000	2400
TUE.	09	BLOW SOOT M.B. 22, 23 & 24	0000	0400
	09	CHANGED BURNER'S MB-23	2000	2400
WED.	10	BLOW SOOT M.B. 22, 23 & 24	0000	0400
	10	CHANGED BURNER'S MB-24	2000	2400
THUR.	11	BLOW SOOT M.B. 22, 23 & 24	0000	0400
	11	CHANGED BURNER'S MB-22	2000	2400
FRI.	12	NO BLOW SOOT M.B. 22, 23 & 24	0000	0400
	12	CHANGED BURNER'S MB-23	2000	2400
SAT	13	BLOW SOOT M.B. 22, 23 & 24	0000	0400
	13	START SKIMMING MB-22 AT 1000 HRS	0800	1200
	13	STOPPED SKIMMING M.B. 22 [redacted] AT 1600 HRS. [redacted]	1200	1600
	13	START SKIMMING M.B. 22 AT 1945 HRS.	1600	2000
	13	CHANGED BURNER'S MB-24	2000	2400
SUN	14	BLOW SOOT M.B. 22, 23 & 24	0000	0400
	14	STOPPED SKIMMING M.B. 22 AT 0145 HRS	0000	0400
	14	CHANGED BURNER'S MB-24	2000	2400

DAY	DA
MON	1
	1
	1
	1
	1
	1
TUE.	1
	1
	1
	1
	1
WED.	1
	1
THUR.	1
	1
	1
FRI.	1
	1
SAT.	2
	2
	2
	2
	2
SUN.	2
	2
MON	2
	2
TUE.	2
	2
WED.	2
	2
THUR.	2
	25

TIME		DAY	DATE		TIME	
000	0400	MON	15	BLOW SOOT M.B. 22, 23 & 24	0000	0400
000	0400		15	START SKIMMING MB-23 AT 0930 HRS	0800	1200
000	2400		15	STOPPED SKIMMING M.B. 23 & CHANGED OVER TO M.B. 24 AT 1530 HRS. (6-HRS.)	1200	1600
000	2400		15	START SLOW FIRING MB-21 2030 HRS	2000	2400
000	0400		15	CHANGED BURNER'S MB-23	2000	2400
00	0800		15	STOPPED SKIMMING MB-24 AT 2130 HRS	2000	2400
000	2400	TUE.	16	BLOW SOOT M.B. 22, 23 & 24	0000	0400
000	0400		16	START SKIMMING MB-23 AT 0800 (6HRS)	0800	1200
00	1200		16	OFF LINE MB-22 AT 11:00 HRS.	0800	1200
000	2400		16	STOPPED SKIMMING M.B. 23 AT 1530 HRS.	1200	1600
000	0400		16	CHANGED BURNER'S MB-24	2000	2400
000	2400	WED.	17	BLOW SOOT M.B. 23 & 24	0000	0400
000	0400		17	CHANGED BURNER'S MB-23	2000	2400
00	1200	THUR.	18	BLOW SOOT M.B. 23 & 24	0000	0400
00	2000		18	ON LINE M.B. 21 AT 17:35 HRS.	1600	2000
000	2400		18	CHANGED BURNER'S MB-24	2000	2400
000	0400	FRI.	18	BLOW SOOT M.B. 21, 23 & 24	0000	0400
000	2400		19	CHANGED BURNER'S MB-23	2000	2400
000	0400	SAT.	20	BLOW SOOT M.B. 21, 23 & 24	0000	0400
000	2400		20	START SKIMMING MB-23 1000 (6HRS)	0800	1200
000	0400		20	STOPPED SKIMMING M.B. 23 & CHANGED OVER TO M.B. 24 AT 1600 HRS. (6-HRS)	1200	1600
000	2400		20	CHANGED BURNER'S MB-21	2000	2400
000	0400		20	STOPPED SKIMMING MB-24 AT 2200	2000	2400
000	2400	SUN.	21	BLOW SOOT M.B. 21, 23 & 24	0000	0400
000	0400		21	CHANGED BURNER'S MB-24	2000	2400
00	1200	MON	22	BLOW SOOT M.B. 21, 23 & 24	0000	0400
00	1600		22	CHANGED BURNER'S MB-21	2000	2400
00	2000	TUE.	23	BLOW SOOT M.B. 21, 23 & 24	0000	0400
000	2400		23	CHANGED BURNER'S MB-23	2000	2400
000	0400	WED.	24	BLOW SOOT M.B. 21, 23 & 24	0000	0400
000	0400		24	CHANGED BURNER'S MB-24	2000	2400
[illegible]	[illegible]	THUR.	25	BLOW SOOT M.B. 21, 23 & 24	0000	0400
			25	CHANGED BURNER'S MB-24	2000	2400

DAY	DATE		TIME	
FRI.	26	BLOW SOOT M.B. 21, 23 & 24	0000	0400
	26	CHANGED BURNER'S MB-23	2000	2400
SAT.	27	BLOW SOOT M.B. 21, 23 & 24	0000	0400
	27	CHANGED BURNER'S MB-24	2000	2400
SUN.	28	BLOW SOOT M.B. 21, 23 & 24	0000	0400
	28	CHANGED BURNER'S MB-21	2000	2400
MON	29	BLOW SOOT M.B. 21 23 & 24	0000	0400
	29	START SLOW FIRING MB-22 AT 2400	2000	2400
	29	CHANGED BURNER'S MB-24	2000	2400
TUE	30	BLOW SOOT M.B. 21, 23 & 24	0000	0400
	30	OFF LINE MB-23 AT 0000	0800	1200
	30	CHANGED BURNER'S MB-21	2000	2400
		* ~ MAY 2002 ~ *		
WED	01	BLOW SOOT M.B. 21 & 24	0000	0400
	01	CHANGED BURNER'S MB-24	2000	2400
THURS.	02	BLOW SOOT M.B. 21 & 24	0000	0400
	02	ON LINE M.B. 22 AT 18:10 HRS.	1600	2000
	02	CHANGED BURNERS MB-21	2000	2400
FRI.	03	BLOW SOOT M.B. 21, 22 & 24	0000	0400
	03	CHANGED BURNER'S MB-24	2000	2400
SAT.	04	NO BLOW SOOT	0000	0400
	04	CHANGED BURNER'S MB-22	2000	2400
SUN.	05	BLOW SOOT M.B. 21, 22 & 24	0000	0400
	05	CHANGED BURNERS M.B. 21 @	2000	2400
MON.	06	BLOW SOOT MB-21, 22, 24	2400	0400
	06	CHANGED BURNERS M.B. 24 @	2000	2400
TUE	07	BLOW SOOT MB-21-22-24	2400	0400
WED	08	BLOW SOOT MB-21-22-24	2400	0400
	08	CHANGED BURNERS M.B. 21 @	2000	2400
THU.	09	BLOW SOOT MB-21-22-24	2400	0400
	09	CHANGED BURNERS M.B. 22 @	2000	2400
FRI.	10	BLOW SOOT MB-21-22-24	2400	0400
	10	CHANGED BURNERS M.B. 24	2000	2400

"MC LON VACATION"

TIME		DAY	DATE		TIME	
000	0400	SAT.	11	BLOW SOOT MB-21-22-24	2400	0400
000	2400		11	CHANGED BURNERS M.B. 21 @	2000	2400
000	0400	SUN.	12	BLOW SOOT MB. 21, 22, & 24	0000	0400
000	2400		12	CHANGED BURNERS M.B. 22 @	2000	2400
000	0400	MON.	13	BLOW SOOT MB. 21, 22 & 24	0000	0400
000	2400		13	START SLOW FIRING MB 23 AT 0051 HRS 2 MINS EVERY 2 HRS	0000	0400
000	0400		13	CHANGED BURNERS M.B. 24 @	2000	2400
000	2400	TUE	14	BLOW SOOT MB. 21, 22, & 24	0000	0400
000	2400		14	OFF LINE M.B. 24 AT 0345 HRS.	0000	0400
000	0400		14	START FIRING M.B. 24 AT 11:00 HRS.	0800	1200
800	1200		14	ON LINE M.B. 24 AT 1350 HRS.	1200	1600
000	2400		14	CHANGED BURNERS M.B. 21 @	2000	0400
		WED.	15	BLOW SOOT MB. 21, 22, 24	0000	0400
000	0400		15	OFF LINE M.B. 24 at 0325 HRS.	0000	0400
000	2400		15	CHANGED BURNERS M.B. 22 @	2000	2400
000	0400	THU.	16	BLOW SOOT MB. 21 & 22	0000	0400
600	2000		16	ON LINE M.B. 23 AT 1745 HRS.	1600	2000
000	2400		16	CHANGED BURNERS M.B. 21 @	2000	2400
000	0400	FRI	17	BLOW SOOT MB. 21, 22, & 23	0000	0400
000	2400		17	CHANGED BURNERS M.B. 22 @	2000	2400
000	0400	SAT	18	BLOW SOOT MB. 21, 22, & 23	0000	0400
000	2400		18	OFF LINE M.B. 23 AT 11:35 HRS.	0800	1200
000	0400		18	CHANGED BURNERS M.B. 21 @	2000	2400
000	2400	SUN	19	BLOW SOOT MB. 21 & 22	0000	0400
000	0400		19	CHANGED BURNERS M.B. 22 @	2000	2400
000	2400	MON.	20	BLOW SOOT MB. 21 & 22	0000	0400
000	0400		20	START FIRING M.B. 23 AT 0125 HRS	0000	0400
000	0400		20	ON LINE M.B. 23 AT 10:00 HRS.	0800	1200
000	2400		20	START SKIMMING MB 21 AT 1400 HRS 4 HRS	1200	1600
000	0400		20	STOPPED SKIMMING M.B. 21 & CHANGED OVER TO M.B. 22 AT 1800 HRS. (4-HRS.)	1600	2000
000	2400		20	CHANGED BURNERS M.B. 21 @	2000	2400
000	0400		20	STOPPED SKIMMING M.B. 22 AT 22:00 HRS. CHANGED OVER M.B. 23 (4 HRS.)	2000	2400
000	2400					

DAY	DATE		TIME	
TUE.	21	BLOW SOOT MB. 21, 22 & 23	0000	0400
	21	STOPPED SKIMMING MB. 23 at 0200 Hrs.	0000	0400
	21	CHANGED BURNERS M.B. 22 @	2000	2400
WED.	22	BLOW SOOT MB. 21, 22 & 23	0000	0400
	22.	CHANGED BURNER M.B. 23 @	2000	2400
THU.	23	BLOW SOOT MB. 21, 22 & 23	0000	0400
	23.	CHANGED BURNERS M.B. 21 @	2000	2400
FRI.	24	BLOW SOOT MB. 21, 22, 23	0000	0400
	24.	CHANGED BURNERS M.B. 22 @	2000	2400
SAT	25	BLOW SOOT MB. 21, 22 & 23	0000	0400
	25	OFF LINE MB. 23 at 1200 Hrs.	1200	1600
SUN.	26	BLOW SOOT MB. 21 & 22 (CANCELLED)	0000	0400
	26	CHANGED BURNERS M.B. 21 @	2000	2400
MON	27	BLOW SOOT MB. 21 & 22	0000	0400
	27	START SLOW FIRING M.B. 22 AT 1825 Hrs.	1600	2000
	27.	CHANGED BURNERS M.B. 22 @	2000	2400
TUE.	28	BLOW SOOT M.B 21 & 22	0000	0400
	28	ON LINE MB. 23 at 0200 Hrs.	0000	0400
	28	CHANGED BURNERS M.B. 21 @	2000	2400
WED	29	BLOW SOOT MB. 21, 22 & 23	0000	0400
	29	CHANGED BURNERS M.B. 23 @	2000	2400
THU.	30	BLOW SOOT MB. 21, 22 & 23	0000	0400
	30	CHANGED BURNERS M.B. 22 @	2000	2400
FRI.	31	BLOW SOOT MB. 21, 22 & 23	0000	0400
	31	CHANGED BURNERS M.B. 21 @	2000	2400
	*	*** JUNE 2002 ***		
SAT.	01	BLOW SOOT MB. 21, 22 & 23	0000	0400
	01	CHANGED BURNERS M.B. 23 @	2000	2400
SUN.	02	BLOW SOOT MB. 21, 22 & 23	0000	0400
	02	CHANGED BURNER'S M.B. 22	2000	2400
MON.	03	BLOW SOOT M.B. 21 = 22 = 23.	0000	0400
	03	CHANGED BURNER'S M.B. 21	2000	2400
TUE.	04	BLOW SOOT M.B. 21 = 22 = 23.	0000	0400
	04	CHANGED BURNER'S M.B 23	2000	2400

DAY	DA
WED.	0
	0
THU.	0
	0
FRI.	0
	0
SAT.	0
	0
SUN.	0
	0
MON.	1
	1
TUE.	1
	1
WED.	1
	1
THU.	1
	1
FRI.	1
	1
	1
	1
	1
SAT.	1
	1
	1
	1
SUN.	1
	1
MON.	1
	1
TUE.	1
	1

(39)

JUNE 2002

TIME		DAY	DATE		TIME	
00	0400	WED.	05	BLOW SOOT M.B. 21 = 22 = 23	0000	0400
00	0400		05	CHANGED BURNER'S M.B. 22	2000	2400
00	2400	THU.	06	BLOW SOOT M.B. 21 = 22 = 23.	0000	0400
00	0400		06	CHANGED BURNER'S M.B. 21	2000	2400
00	2400	FRI.	07	BLOW SOOT M.B. 21 = 22 = 23 @	0000	0400
00	0400		07	CHANGED BURNER'S M.B. 23	2000	2400
00	2400	SAT.	08	BLOW SOOT M.B. 21 = 22 = 23 @	0000	0400
00	0400		08	CHANGED BURNER'S M.B. 22	2000	2400
00	2400	SUN.	09	BLOW SOOT M.B. 21 = 22 = 23 @	0000	0400
00	0400		09	CHANGED BURNER'S M.B. 21	2000	2400
00	1600	MON.	10	BLOW SOOT M.B. 21 = 22 = 23 @	0000	0400
00	0400		10	CHANGED BURNER'S M.B. 23	2000	2400
00	2400	TUE.	11	BLOW SOOT M.B. 21 = 22 = 23 @	0000	0400
00	0400		11	CHANGED BURNER'S M.B. 22	2000	2400
00	2000	WED.	12	BLOW SOOT M.B. 21 = 22 = 23 @	0000	0400
00	2400		12	CHANGED BURNER'S M.B. 21	2000	2400
00	0400	THU.	13	BLOW SOOT M.B. 21 = 22 = 23 @	0000	0400
00	0400		13	CHANGED BURNER'S M.B. 23	2000	2400
00	2400	FRI.	14	BLOW SOOT M.B. 21 = 22 = 23 @	0000	0400
00	0400		14	START SKIMMING M.B. 22 AT (1300 HRS)	1200	1600
00	2400		14	STOPPED SKIMMING M.B. 22, CHANGED M.B. 23	1600	2000
00	0400		14	CHANGED BURNER'S M.B. 22	2000	2400
00	2400		14	STOPPED SKIMMING M.B. 23 AT 2100 HRS.	2000	2400
00	0400	SAT.	15	BLOW SOOT M.B. 21 = 22 = 23 @	0000	0400
00	2400		15	START SKIMMING M.B. 23 AT (15:30 HRS)	1200	1600
			15	STOPPED SKIMMING M.B. 23 AT (1930 HRS)	1600	2000
00	0400		15	CHANGED BURNER'S M.B. 21	2000	2400
00	2400	SUN.	16.	BLOW SOOT M.B. 21 = 22 = 23 @	0000	0400
00	0400		16	CHANGED BURNER'S M.B. 23	2000	2400
00	2400	MON.	17	BLOW SOOT M.B. 21 = 22 = 23	0000	0400
00	0400		17	CHANGED BURNER'S M.B. 22	2000	2400
00	2400	TUE.	18	BLOW SOOT M.B. 21 = 22 = 23.	0000	0400
00	0400		18	CHANGED BURNER'S M.B. 21	2000	2400
00	2400					

DAY	DATE		TIME		DAY	DATE
WED.	19.	BLOW SOOT M.B. 21 = 22 = 23 @	0000	0400	SUN.	30
	19	START SKIMMING M.B. 22 1500 HRS (8 HRS)	1200	1600		30
	19	CHANGED BURNER'S M.B. 23	2000	2400		30
	19	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 23 AT 2300 HRS. (8 HRS)	2000	2400		30
THU.	20.	BLOW SOOT M.B. 21 = 22 = 23 = @.	0000	0400		30
	20	STOPPED SKIMMING MB. 23 AT 0700 HRS	0400	0800		
	20.	START SKIMMING M.B. 22. AT 1400 HRS. (8 HRS.)	1200	1600	MON.	01
	20	CHANGED BURNER'S M.B. 22	2000	2400		01
	20	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 23 AT 2200 HRS. (8 HRS)	2000	2400	TUE.	02
FRI.	21	BLOW SOOT M.B. 21 = 22 = 23 @	0000	0400		02
	21	STOPPED SKIMMING MB. 23 AT 0600 HRS.	0400	0800		02
	21	CHANGED BURNER'S M.B. 21	2000	2400	WED.	03
SAT.	22	BLOW SOOT M.B. 21 = 22 = 23 @	0000	0400		03
	22.	START SKIMMING M.B. 23 AT 02:00 HRS (8 HRS)	0000	0400	THU.	04
	22	STOPPED SKIMMING M.B. 23 AT 10.00 HRS.	0800	1200		04
	22	CHANGED BURNER'S M.B. 23	2000	2400	FRI.	05
SUN.	23	BLOW SOOT M.B. 21 = 22 = 23 = @	0000	0400		05
	23	CHANGED BURNER'S M.B. 22	2000	2400		05
MON.	24	BLOW SOOT M.B. 21 = 22 = 23 = @	0000	0400	SAT.	06
	24	CHANGED BURNER'S M.B. 21	2000	2400		06
TUE.	25	BLOW SOOT M.B. 21 = 22 = 23 =	0000	0400		06
	25.	START SKIMMING M.B. 23 AT 1300 HRS.	1200	1600	SUN.	07
	25	CHANGED BURNER'S M.B. 23	2000	2400		07
	25	STOPPED SKIMMING M.B. 23 AT 2300 HRS.	2000	2400		07
WED.	26	BLOW SOOT M.B. 21 = 22 = 23 = @	0000	0400	MON.	08
	26	CHANGED BURNER'S M.B. 22	2000	2400		08
THU.	27.	BLOW SOOT M.B. 21 = 22 = 23 @	0000	0400		08
	27	START FIRING MB. 24 AT 1700 HRS.	1600	2000	TUE.	09
	27	CHANGED BURNER'S M.B. 21	2000	2400		09
FRI.	28	BLOW SOOT M.B. 21 = 22 = 23 @	0000	0400		09
	28	ON LINE M.B. 24 AT 0940 HRS.	0800	1200	WED.	10
SAT.	29	BLOW SOOT M.B. 21 = 22 = 23 = 24 = @	0000	0400		10
	29	OFF LINE M.B. 23 AT. 12:20 HRS.	1200	1600	THU.	11
	29	CHANGED BURNERS M/B # 21	2000	2400		11

TIME		DAY	DATE		TIME	
00	0400	SUN.	30	BLOW SOOT M.B. 21 = 22 = 24 @	0000	0400
00	1600		30	OFF LINE M.B. 22 AT. 03:05 HRS.	0000	0400
00	2400		30	START SLOW FIRING M.B. 22 AT. 17:20 HRS.	1600	2000
00	2400		30	CHANGED BURNER'S MB. 24	2000	2400
00	0400		30	ON LINE MB. 22 AT 22:15 HRS.	2000	2400
00	0800			2002. JULY 2002.		
00	1600	MON.	01	BLOW SOOT M.B. 21, 22 & 24	0000	0400
00	2400		01	CHANGED BURNER'S M.B. 21	2000	2400
00	2400	TUE.	02	BLOW SOOT M.B. 21, 22 & 24	0000	0400
00	0400		02	OFF LINE M.B. 21 AT. 17:10 HRS.	1600	2000
00	0800		02	CHANGED BURNER'S MB. 22	2000	2400
00	2400	WED.	03	BLOW SOOT M.B. 22 & 24	0000	0400
00	0400		03	CHANGED BURNERS MB. 24	2000	2400
00	0400	THU.	04	BLOW SOOT M.B. 22 & 24	0000	0400
00	1200		04	CHANGED BURNER'S MB. 22	2000	2400
00	2400	FRI.	05	BLOW SOOT M.B. 22 & 24	0000	0400
00	0400		05	START SLOW FIRING M.B. 21 AT. 17:35 HRS.	1600	2000
00	2400		05	CHANGED BURNER'S MB. 24	2000	2400
00	0400	SAT.	06	ON LINE MB # 21 AT 0010 HRS.	0000	0400
00	2400		06	BLOW SOOT M.B. 21, 22 & 24	0000	0400
00	0400		06	CHANGED BURNER'S M.B. 22	2000	2400
00	1600	SUN.	07	BLOW SOOT M.B. 21, 22 & 24	0000	0400
00	2400		07	OFF LINE MB. 21 AT. 08:45 HRS. (LEAKING)	0400	0800
00	2400		07	CHANGED BURNER'S M.B. 24	2000	2400
00	0400	MON.	08	BLOW SOOT M.B. 22 & 24	0000	0400
00	2400		08	CHANGED BURNER'S MB. 22	2000	2400
00	0400		08	START FIRING M.B. 21 AT 1210 HRS.	2000	2400
00	2000	TUE.	09	BLOW SOOT M.B. 22 & 24	0000	0400
00	2400		09	ON LINE MB. 21 AT 0830 HRS	0800	1200
00	0400		09	CHANGED BURNER'S MB. 24	2000	2400
00	1200	WED.	10	BLOW SOOT M.B. 21, 22 & 24	0000	0400
00	0400		10	CHANGED BURNER'S MB. 22	2000	2400
00	1600	THU.	11	BLOW SOOT M.B. 21, 22 & 24	0000	0400
00	2400		11	CHANGED BURNER'S MB. 21	2000	2400

JULY 2002

DAY.	DATE		TIME	
FRI.	12	BLOW SOOT M.B. 21, 22 & 24	0000	0400
	12	CHANGED BURNER'S MB. 24	2000	2400
SAT.	13	BLOW SOOT M.B. 21, 22 & 24	0000	0400
	13	CHANGED BURNER'S MB. 22	2000	2400
SUN.	14	BLOW SOOT M.B. 21, 22 & 24	0000	0400
	14	OFF LINE M.B 24 AT 11 30 HRS.	0800	1200
	14	CHANGED BURNERS MB. 21	2000	2400
MON.	15	BLOW SOOT M.B. 21 & 22	0000	0400
	15	START SLOW FIRING M.B. 23 AT 1400 HRS	1200	1600
	15	CHANGED BURNER'S MB. 22	2000	2400
	15	ON LINE MB. 23 AT 2140 HRS.	2000	2400
TUE.	16	BLOW SOOT M.B. 21, 22 & 23	0000	0400
	16	CHANGED BURNER'S MB. 21 (CANCELLED OFF LINE)	2000	2400
WED.	17	BLOW SOOT M.B. 21, 22 & 23	0000	0400
	17	OFF LINE M.B. 21 AT 0800 HRS.	0400	0800
	17	CHANGED BURNER'S MB. 23	2000	2400
	17	TEST FIRING MB. 24 AT 2355 HRS	2000	2400
THU.	18	BLOW SOOT M.B. 22 & 23	0000	0400
	18	START FIRING M.B. 24 AT 0900 HRS	0800	1200
	18	ON LINE M.B. 24 AT 17:50 HRS.	1600	2000
	18	CHANGED BURNER'S MB. 22	2000	2400
FRI.	19	BLOW SOOT M.B. 22, 23 & 24	0000	0400
	19	START FIRING MB. 21 AT 1015 HRS.	0800	1200
	19	CHANGED BURNERS MB. 23	2000	2400
SAT.	20	BLOW SOOT M.B. 22, 23 & 24	0000	0400
	20	OFF LINE M.B. 24 AT 1245 HRS	1200	1600
	20	ON LINE M.B. 24 AT 19:40 HRS.	1600	2000
SUN.	21	BLOW SOOT M.B. 22, 23 & 24	0000	0400
	21	OFF LINE M.B. 24 AT 05:50 HRS.	0400	0800
	21	ON LINE M.B. 24 AT 17:10 HRS.	1600	2000
	21	CHANGED BURNER'S MB. 22	2000	2400
MON.	22	BLOW SOOT M.B. 22, 23 & 24	0000	0400
	22	CHANGED BURNER'S MB. 23	2000	2400

DAY	DATE
TUE	23
	23
WED	24
	24
	24
	24
THU.	25
	25
	25
	25
	25
	25
	25
FRI.	26
	26
SAT	27
	27
	27
SUN.	28
	28
	28
	28
MON.	29
	29
TUE.	30
	30
	30
WED	31
	31
THU	01
	01
	01
	01

TIME		DAY	DATE		TIME	
000	2400	TUE	23	BLOW SOOT M.B. 22, 23 & 24	0000	0400
000	2400		23	NO CHANGED BURNERS	2000	2400
000	0400	WED	24	BLOW SOOT M.B. 22, 23 & 24	0000	0400
000	2400		24	OFF LINE M.B. 24 AT 0250 HRS	0000	0400
000	0400		24	CHANGED BURNERS M.B. 22	2000	2400
800	1200		24	TEST FIRING MB-24 AT 2130 HRS.	2000	2400
000	2400	THU.	25	BLOW SOOT M.B. 22 & 23	0000	0400
000	0400		25	START FIRING MB-24 @ 0816 HRS.	0800	1200
200	1600		25	TEST FIRING MB-21 @ 1100 HRS.	0800	1200
000	2400		25	START FIRING M.B. 21 AT 1400 HRS	1200	1600
000	2400		25	ON LINE M.B. 24 AT 15 25 HRS	1200	1600
000	0400		25	STOPPED FIRING M.B. 21 AT 18:30 HRS. LEAK	1600	2000
000	2400		25	CHANGED BURNERS MB-23	2000	2400
000	0400	FRI.	26	BLOW SOOT M.B. 22, 23 & 24	0000	0400
400	0800		26	CHANGED BURNERS M.B. 22	2000	2400
000	2400	SAT	27	BLOW SOOT M.B. 22, 23 & 24	0000	0400
000	2400		27	OFF LINE M.B. 24 AT 1400 HRS	1200	1600
000	0400		27	ON LINE M.B. 24 AT 19:25 HRS.	1600	2000
800	1200	SUN.	28	BLOW SOOT M.B. 22, 23 & 24	0000	0400
600	2000		28	OFF LINE M.B. 24 AT 05:45 HRS.	0400	0800
000	2400		28	ON LINE M.B. 24 AT 1735 HRS	1600	2000
000	0400		28	CHANGED BURNERS M.B. 23 @	2000	2400
800	1200	MON.	29	BLOW SOOT M.B. 22, 23 & 24	0000	0400
000	2400		29	CHANGED BURNERS M.B. 22 @	2000	2400
000	0400	TUE.	30	BLOW SOOT M.B. 22, 23, & 24	0000	0400
200	1600		30	CHANGED BURNERS M.B. 24 @	2000	2400
1600	2000		30	OFF LINE M.B. 24 AT 23:45 HRS.	2000	2400
000	0400	WED	31	BLOW SOOT M.B. 22 & 23	0000	0400
400	0800		31	CHANGED BURNERS M.B. 23 @	2000	2400
600	2000			August 2002		
000	2400	THU	01	BLOW SOOT M.B. 22 & 23	0000	0400
000	0400		01	START SLOW FIRING M.B. 24 08:00 HRS.	0800	1200
000	2400		01	ON LINE M.B. 24 AT 1700 HRS	1600	2000
			01	CHANGED BURNERS M.B. 22 @	2000	2400

August 2002

DAY	DATE		TIME		DAY	DA
FRI.	02	BLOW SOOT M.B. 22, 23 & 24	0000	0400	SUN.	1
	02	SLOW FIRING M.B. 21 AT 1217 HRS.	1200	1600		1
	02	ON LINE M.B. 21 AT 20:10 HRS.	2000	2400	MON.	1
SAT.	03	BLOW SOOT M.B. 21, 22, 23, & 24	0000	0400		1
	03	OFF LINE M.B. 23 AT 11:40 HRS.	0800	1200	TUE.	1
	03	OFF LINE M.B. 22 AT 1300 HRS	1200	1600		1
	03	ON LINE M.B. 22 AT 1820 HRS	1600	2000	WED.	1
	03	CHANGED BURNERS M.B. 24 @	2000	2400		1
SUN.	04	BLOW SOOT M.B. 21, 22 & 24	0000	0400		1
	04	OFF LINE M.B. 24 05:00 HRS.	0400	0800		1
	04	ON LINE M.B. 24 AT 1735 HRS	1600	2000		1
	04	CHANGED BURNERS M.B. 21 @	2000	2400	THU.	1
MON	05	BLOW SOOT M.B. 21, 22, & 24	0000	0400		1
	05	CHANGED BURNERS M.B. 22 @	2000	2400	FRI.	1
TUE	06	BLOW SOOT M.B. 21, 22 & 24	0000	0400		1
	06	CHANGED BURNERS M.B. 24 @	2000	2400		1
WED.	07	BLOW SOOT M.B. 21, 22, & 24	0000	0400		1
	07	CHANGED BURNERS M.B. 21 @	2000	2400	SAT.	1
	07	START SKIMMING M.B. 24 AT 22:00 HRS (8)	2000	2400		1
THU.	08	BLOW SOOT M.B. 21, 22 & 24	0000	0400		1
	08	STOPPED SKIMMING M.B. 24 & CHANGED OVER TO M.B. 21 AT 0600 HRS.	0400	0800	SUN.	1
	08.	STOPPED SKIMMING M.B. 21, CHANGED OVER TO M.B. 22 AT 1400 HR (8 HRS)	1200	1600		1
	08	CHANGED BURNERS M.B. 22 @	2000	2400		1
	08.	START SLOW FIRING M.B. 23 AT 21:05 HRS.	2000	2400	MON	1
	08.	STOPPED SKIMMING M.B. 22 AT 2200 H.	2000	2400		1
FRI.	09	BLOW SOOT M.B. 21, 22, 24	0000	0400		1
	09	STOPPED SKIMMING M.B. 22 AT 0100 HRS	0000	0400		1
	09	ON LINE M.B. 23 AT 0345 HRS.	0000	0400	TUE.	2
	09	OFF LINE M.B. 21 AT 0415 HRS;	0400	0800	WED.	2
	09	CHANGED BURNERS M.B. 24 @	2000	2400		2
SAT.	10	BLOW SOOT M.B. 22, 23, & 24	0000	0400		2
	10	CHANGED BURNERS M.B. 23	2000	2400	THU.	2
	*	* * * * * *	*	*		2
						2

TIME		DAY	DATE		TIME	
000	0400	SUN.	11	BLOW SOOT M.B. 22, 23, & 24	0000	0400
200	1600		11	CHANGED BURNERS M.B. 22 @	2000	2400
000	2400	MON.	12	BLOW SOOT M.B. 22, 23, & 24	0000	0400
000	0400		12	CHANGED BURNERS M.B. 24 @	2000	2400
800	1200	TUE.	13	BLOW SOOT M.B. 22, 23, & 24	0000	0400
200	1600		13	CHANGED BURNERS M.B. 23 @	2000	2400
600	2000	WED.	14	BLOW SOOT M.B. 22, 23, & 24	0000	0400
000	2400		14	START SLOW FIRING M.B. 21 AT 11:00 HRS. 5 MIN. 20-	0800	1200
000	0400		14	CHANGED BURNERS M.B. 22. @	2000	2400
400	0800		14	ON LINE M.B. 21 AT. 22:10 HRS.	2000	2400
000	2000		14	OFF LINE M.B. 23 AT 22:20 HRS.	2000	2400
000	2400	THU.	15	BLOW SOOT M.B. 2, 21, 22, & 24	0000	0400
000	0400		15	CHANGED BURNERS M.B. 24 @	2000	2400
000	2400	FRI.	16	BLOW SOOT M.B. 21, 22, & 24	0000	0400
000	0400		16	START SKIMMING M.B. 24 AT 0311 HRS	0000	0400
000	2400		16	STOPPED SKIMMING M.B. 24 AT 0800 HRS	0400	0800
000	0400		16	CHANGED BURNERS M.B. 21 @	2000	2400
000	2400	SAT.	17	BLOW SOOT M.B. 22, 23, & 24	0000	0400
000	2400		17	~~OFF LINE M.B. 22 (AT)~~ (CANCELLED)		
000	0400		17	CHANGED BURNERS M.B. 24 @	2000	2400
400	0800	SUN.	18	BLOW SOOT M.B. 21, 22, & 24	0000	0400
200	1600		18	OFF LINE M.B. 22 AT 0230 HRS.	0000	0400
000	2400		18	CHANGED BURNERS M.B. 21 @	2000	2400
000	2400	MON	19	BLOW SOOT M.B. 21 & 24	0000	0400
000	2400		19	START FIRING M.B. 23 AT 14:50 HRS	1200	1600
000	0400		19	CHANGED BURNERS M.B. 24 @	2000	2400
000	0400		19	ON Line M.B. 23 AT = 23:00 HRS.	2000	2400
000	0400	TUE.	20	BLOW SOOT M.B. 21, 23, & 24	0000	0400
400	0800	WED.	21	BLOW SOOT M.B. 21, 23, & 24	0000	0400
000	2400		21	OFF LINE M.B. 21 = 07:50 HRS.	0400	0800
000	0400		21	CHANGED BURNERS M.B. 23 @	2000	2400
000	2400	THU.	22	BLOW SOOT M.B. 23, & 24	0000	0400
*	*		22.	START SLOW FIRING M.B. 22 = 08:30 H.	0800	1200
			22	ON LINE M.B. 22 AT 1640 HRS.	1600	2000

DAY	DATE		TIME	
THU.	22.	CHANGED BURNERS M.B. 24 @	2000	2400
FRI.	23	BLOW SOOT M.B. 22, 23 & 24	0000	0400
	23	CHANGED BURNERS M.B. 23 @	2000	2400
SAT.	24	BLOW SOOT M.B. 22, 23, & 24	0000	0400
	24	OFF LINE M.B. 24 = 10:40 HRS.	0800	1200
	24	CHANGED BURNERS M.B. 22 @	2000	2400
	24	ON LINE M.B. 24 = 21:00 HRS.	2000	2400
SUN	25	BLOW SOOT M.B. 22, 23, & 24	0000	0400
	25	CHANGING OF WATCH * * *	1200	1600
	25	CHANGED BURNER'S M.B. 24	2000	2400
MON.	26.	BLOW SOOT M.B. 22 = 23 = 24	0000	0400
	26	SKIMMING M.B. 24 AT 1700 HRS. (6 HRS)	1600	2000
	26	CHANGED BURNER'S M.B. 23	2000	2400
	26	STOPPED SKIMMING M.B. 24 AT 2300 HRS	2000	2400
TUE.	27	BLOW SOOT M.B. 22 = 23 = 24 = @	0000	0400
	27	SKIMMING M.B. 23 AT 1700 HRS (6 HRS.)	1600	2000
	27	CHANGED BURNER'S M.B. 22	2000	2400
	27	STOPPED SKIMMING M.B. 23 AT 2300 HRS.	2000	2400
WED.	28	BLOW SOOT M.B. 22 = 23 = 24 @	0000	0400
	28	SKIMMING M.B. 24 AT 02:00 HRS. (6 HRS.)	0000	0400
	28	STOPPED SKIMMING M.B. 24 AT 0800 HRS	0400	0800
	28	CHANGED BURNER'S M.B. 24	2000	2400
THU.	29	BLOW SOOT M.B. 22 = 23 = 24 @	0000	0400
	29	CHANGED BURNER'S M.B. 23	2000	2400
FRI.	30	BLOW SOOT M.B. 22 = 23 = 24 @	0000	0400
	30	CHANGED BURNER'S M.B. 22	2000	2400
SAT.	31	BLOW SOOT M.B. 22 = 23 = 24 @	0000	0400
	31	CHANGED BURNER'S M.B. 24	2000	2400

SEPTEMBER. 2002.

SUN.	01	BLOW SOOT M.B. 22 = 23 = 24	0000	0400
	01	CHANGED BURNER'S M.B. 23	2000	2400
MON.	02	BLOW SOOT M.B. 22 = 23 = 24 @	0000	0400
	02	START SKIMMING MB 22 AT 1745 HRS (6 HRS)	1600	2000

TIME	DAY	DATE		TIME	
2400	MON.	02	CHANGED BURNER'S M.B. 22	2000	2400
0400		02	STOPPED SKIMMING M.B. 22 AT 2345 HRS.	2000	2400
2400		02	START SKIMMING M.B. 23 AT 2345 HRS.	2000	2400
0400	TUE.	03	BLOW SOOT M.B. 22 = 23 = 24 = @	0000	0400
1200		03	STOPPED SKIMMING M.B. 23 AT 0445 HRS	0400	0800
2400		03	OFF LINE M.B. 22 AT 0520 HRS	0400	0800
2400		03	~~BOTTOM~~ BLOW DOWN M.B. 22 15 MIN	0400	0800
0400		03	~~START~~ SKIMMING M.B. 24 AT 0545 HRS	0400	0800
1600		03	STOPPED SKIMMING M.B. 24 AT 1145 HRS.	0800	1200
2400		03	START SKIMMING M.B. 22 AT 1630 HRS (left)	1600	2000
0400		03	CHANGED BURNER'S M.B. 24	2000	2400
2000		03	STOPPED SKIMMING M.B. 24 & CHANGED OVER TO M.B. 23 AT 2230 HRS. (6 HRS)	2000	2400
2400	WED.	04	BLOW SOOT M.B. 23 = 24 @	0000	0400
2400		04	STOPPED SKIMMING M.B. 23 AT 01:30 HRS.	0000	0400
0400		04	CHANGED BURNER'S M.B. 23	2000	2400
2000	THU.	05	BLOW SOOT M.B. 23 = 24 @	0000	0400
2400		05	START SLOW FIRING M.B. 21 AT 0830 HRS.	0800	1200
2400		05	ON LINE M.B. 21 AT 1740 HRS.	1600	2000
0400		05	CHANGED BURNER'S M.B. 24	2000	2400
0400	FRI.	06	BLOW SOOT M.B. 21 = 23 = 24 @	0000	0400
0800		06	CHANGED BURNER'S M.B. 21	2000	2400
2400	SAT.	07	BLOW SOOT M.B. 21 = 23 = 24 @	0000	0400
0400		07	CHANGED BURNER'S M.B. 23	2000	2400
2400	SUN.	08	BLOW SOOT M.B. 21 = 23 = 24 = @	0000	0400
0400		08	CHANGED BURNER'S M.B. 24	2000	2400
2400	MON.	09	BLOW SOOT M.B. 21 = 23 = 24 = @	0000	0400
0400		09	START SKIMMING M.B. 21 AT 1700 HRS.	1600	2000
2400		09	CHANGED BURNER'S M.B. 21	2000	2400
		09	STOPPED SKIMMING M.B. 21 & CHANGED OVER TO M.B. 23 AT 2300 HRS. (6 HRS)	2000	2400
	TUE.	10	BLOW SOOT M.B. 21 = 23 = 24 @	0000	0400
0400		10	STOPPED SKIMMING M.B. 23 & CHANGED OVER TO M.B. 24 AT 0500 HRS. (6 HRS)	0400	0800
2400		10	STOPPED SKIMMING M.B. 24 AT 1100 HRS.	0800	1200
0400		10	CHANGED BURNER'S M.B. 23	2000	2400
2000					

"MC LON ON DUTY"

DAY	DATE		TIME		DAY	DATE
WED.	11	BLOW SOOT M.B. 21=22=24@.	0000	0400	SUN.	22
	11	CHANGED BURNER'S M.B. 24	2000	2400		22
THU.	12	BLOW SOOT M.B. 21=23=24@	0000	0400	*	22
	12	START SLOW FIRING M.B. 21 2040 HRS.	2000	2400		22
FRI.	13	BLOW SOOT M.B. 23=24=	0000	0400	MON	23
	13	ON LINE M.B. 22 AT 0415 HRS.	0400	0800		23
	13	CHANGED BURNER'S M.B. 23	2000	2400		23
SAT.	14	BLOW SOOT M.B. 22=23=24=@	0000	0400		23
	14	OFF LINE M.B. 21 AT 1030 HRS. BOTTOM BLOW M.B. 21 (15 MINS.)	0800	1200		23
	14	CHANGED BURNER'S M.B. 24	2000	2400		23
SUN	15	BLOW SOOT MB-22-23-24	0000	0400		23
	15	OFF LINE MB-24 AT 0240 HRS. BOTTOM BLOW MB-24 (15 MINS.)	0000	0400	TUE.	24
	15	CHANGED BURNER'S M.B. 22	2000	2400		24
MON	16	BLOW SOOT MB-22-23	0000	0400		24
	16	START FIRING MB-24 1210 HRS.	1200	1600		24
	16	START SKIMMING MB 23 AT (1720) HRS.	1600	2000		24
	16	ON LINE MB-24 AT (1900) HRS.	1600	2000	WED	25
	16	CHANGED BURNER'S M.B. 23	2000	2400		25
	16	STOPPED SKIMMING M.B. 23 AT 2320 HRS.	2000	2400		25
TUE	17	BLOW SOOT MB-22-23-24	0000	0400		25
	17	CHANGED BURNER'S M.B. 22	2000	2400	THU.	26
WED	18	BLOW SOOT MB-22-23-24	0000	0400		26
	18	START SLOW FIRING M.B 21 AT 1915 HRS	1600	2000		26
	18	CHANGED BURNER'S M.B. 24	2000	2400	FRI.	27
THU	19	BLOW SOOT MB-22-23-24	0000	0400		27
	19	ON LINE MB-21 AT 0300 HRS. OFF LINE MB-23 AT 0810 HRS.	0000	0400	SAT.	28
FRI.	20	BLOW SOOT MB-22-23-24	0000	0400		28
	20	CHANGED BURNER'S M.B. 22	2000	2400		28
SAT.	21	BLOW SOOT MB-22-21-24	0000	0400	SUN.	29
	21	START SLOW FIRING M.B. 23 AT 0930 HRS.	0800	1200		29
	21	OFF LINE M.B. 22 AT 1120 HRS. BOTTOM BLOW DOWN M.B. 22 (5 MINS)	0800	1200		29
	21	ON LINE MB 23 AT 1910 HRS.	1600	2000	MON	30
	21	CHANGED BURNER'S M.B. 24	2000	2400		30
						30

TIME		DAY	DATE		TIME	
0	0400	SUN.	22	BLOW SOOT MB-21-23-24	0000	0400
0	2400		22	OFF LINE MB-21 AT 0230 HRS. BOTTOM BLOW DOWN MB-21 15 MINS.	0000	0400
0	0400	*	22	CHANGING OF WATCH * * *	1200	1600
0	2400		22	CHANGED BURNERS M.B. 23.	2000	2400
0	0400	MON	23	BLOW SOOT M.B. 23 & 24	0000	0400
0	0800		23	START SKIMMING MB-24 AT 0500	0400	0800
0	2400		23	STOP SKIMMING MB-24 AT (1100 HRS.) AND CHANGED OVER TO MB. 23 (6 HRS.)	0800	1200
0	0400		23	START SLOW FIRING M.B. 22 AT 1545 Hrs.	1200	1600
0	1200		23	STOP SKIMMING MB-23 AT 1700 HRS.	1600	2000
0	2400		23	CHANGED BURNERS MB. 24	2000	2400
0	0400		23	ON LINE MB 22 AT (2220 HRS.)	2000	2400
0	0400	TUE.	24	BLOW SOOT M.B. 22, 23 & 24	0000	0400
0	2400		24	START SKIMMING M.B. 22 AT (0940 HRS.)	0800	1200
0	0400		24	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 23 AT 1540 HRS. (6-HRS.)	1200	1600
0	1600		24	CHANGED BURNERS MB 23	2000	2400
0	2000		24	STOPPED SKIMMING M-B-23 AT 2140 AND CHANGED OVER TO M.B-24	2000	2400
0	2000	WED	25	BLOW SOOT M.B. 22, 23 & 24	0000	0400
0	2400		25	STOPPED SKIMMING M.B. 24 AT 0340 Hrs.	0000	0400
200	2400		25	START SKIMMING MB-22 AT 1900 HRS	1600	2000
0	0400		25	CHANGED BURNERS M.B 22	2000	2400
0	2400	THU.	26	BLOW SOOT M.B. 22, 23 & 24	0000	0400
0	0400		26	STOPPED SKIMMING M.B. 22 AT 0200 Hrs.	0000	0400
0	2000		26	CHANGED BURNERS M.B. 24	2000	2400
0	2400	FRI.	27	BLOW SOOT M.B. 22, 23 & 24	0000	0400
0	0400		27	CHANGED BURNERS M.B. 23	2000	2400
0	0400	SAT.	28	BLOW SOOT M.B. 22, 23 & 24	0000	0400
0	0400		28	OFF LINE MB 24 AT 1100 HRS. BOTTOM BLOW DOWN (10 MINS.)	0800	1200
0	2400		28	CHANGED BURNERS M.B. 22	0800	1200
0	0400	SUN.	29	BLOW SOOT M.B. 22 & 23	0000	0400
0	1200		29	CHANGED BURNERS M.B 23	2000	2400
0	1200		29	START SLOW FIRING M.B. 21 AT (2200)	2000	2400
	2000	MON	30	BLOW SOOT M.B. 22 & 23	0000	0400
0	2400		30	ON LINE MB-21 AT 0200 HRS.	0400	0800
			30	START SKIMMING M.B. 21 AT 0945	0800	1200

DAY	DATE		TIME		DAY	DATE
MON.	30	STOPPED SKIMMING M.B. 21 & CHANGED OVER TO M.B. 22 AT 1545 HRS. (6-HRS)	1200	1600	WED	09
	30	CHANGED BURNERS M.B 22	2000	2400		09
	30	STOPPED SKIMMING M.B 22 (AT 2145 HRS.) CHANGED OVER TO M.B. 23 (6 HRS)	2000	2400	THU.	10
* OCT. 3		RAMON VILLARAIS START TRAINING W/ "FAENG.." *				10
		"OCTOBER 2002"				10
TUE.	01	BLOW SOOT M.B. 21, 22 & 23	0000	0400	FRI.	11
	01	STOPPED SKIMMING M.B. 23	0000	0400		11
	01	CHANGED BURNERS M.B. 21	2000	2400	SAT.	12
WED.	02	BLOW SOOT M.B. 21, 22 & 23	0000	0400		12
	02	CHANGED BURNERS M.B. 23	2000	2400		12
THURS.	03	BLOW SOOT M.B. 21, 22 & 23	0000	0400		12
	03	CHANGED BURNERS M.B. 22	2000	2400		12
FRI.	04	BLOW SOOT M.B. 21, 22 & 23	0000	0400		12
	04	CHANGED BURNERS, M.B. 21	2000	2400	SUN.	13
SAT.	05	BLOW SOOT M.B. 21, 22 & 23	0000	0400		13
	05	OFF LINE M.B 23 AT (1125 HRS.) BOTTOM BLOW DOWN (15 MINS.)	0800	1200	MON.	14
	05	CHANGED BURNERS M.B. 22	2000	2400		14
SUN.	06	BLOW SOOT M.B. 21 & 22	0000	0400		14
	06	CHANGED BURNERS M.B 21	2000	2400		14
	06	START SLOW FIRING M.B 24 AT (0940 HRS)	2000	2400		14
MON.	07	BLOW SOOT M.B. 21 & 22	0000	0400		14
	07	ON LINE MB# 24 AT 0530 HRS	0400	0800		14
	07	START SKIMMING MB 21 AT 0915 HRS.	0800	1200	TUE.	15
	07	STOPPED SKIMMING M.B. 21 & CHANGED OVER TO M.B. 22 AT 1515 HRS. (6-HRS)	1200	1600		15
	07	STOPPED SKIMMING MB-22 AT 1730 HRS CHANGED OVER MB-24 AT 1730 HRS (6 HRS)	1600	2000		15
	07	CHANGED BURNER M.B. 22 (2130)	2000	2400		15
	07	STOPPED SKIMMING M.B. 24 (2345)	2000	2400		15
TUE.	08	BLOW SOOT M.B. 21, 22 & 24	0000	0400		15
	08	START SKIMMING MB 22 (0930)	0800	1200		15
	08	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 21 AT 1530 HRS. (6-HRS)	1200	1600	WED.	16
	08	CHANGED BURNERS M.B. 24	2000	2400		16
	08	STOPPED SKIMMING MB 22 AT (2130 HRS) AND CHANGED OVER TO MB 24 (6 HRS)	2000	2400		16
WED	09	BLOW SOOT M.B. 21, 22 & 24	0000	0400	THU.	17
	09	STOPPED SKIMMING M.B. 24 AT 0330 HRS.	0000	0400		17

"OCTOBER 2002"

TIME		DAY	DATE		TIME	
:00	1600	WED	09	START SKIMMING MB 22 AT (2020 HRS.)	2000	2400
0	2400		09	CHANGED BURNERS MB 21	2000	2400
00	2400	THU.	10	BLOW SOOT M.B. 21, 22 & 24	0000	0400
6...	*		10	STOPPED SKIMMING M.B. 22 AT 0220 HRS	0000	0400
			10	CHANGED BURNERS MB 22	2000	2400
00	0400	FRI.	11	BLOW SOOT M.B. 21, 22 & 24	0000	0400
00	0400		11	CHANGED BURNERS M.B 24	2000	2400
00	2400	SAT.	12	BLOW SOOT M.B. 21, 22 & 24	0000	0400
00	0400		12	OFF LINE MB 22 AT 1110 HRS	0800	1200
00	2400		12	BOTTOM BLOW DOWN (15 MINS.)	0800	1200
00	0400		12	OFF LINE M.B. 24 AT 1305 HRS.	1200	1600
00	2400		12	ON LINE M.B.#24 AT 1730 HRS	1600	2000
00	0400		12	CHANGED BURNERS MB 21	2000	2400
00	2400	SUN.	13	BLOW SOOT M.B. 21 & 24	0000	0400
00	0400		13	CHANGED BURNERS M.B. 24	2000	2400
00	1200	MON.	14	BLOW SOOT M.B. 21 & 24	0000	0400
00	2400		14	SLOW FIRING MB 23 AT (0840 HRS.)	0800	1200
00	0400		14	START SKIMMING MB 24 AT (1000 HRS.)	0800	1200
00	2400		14	STOPPED SKIMMING MB#24 AT 1600 HRS CHANGED OVER TO MB#21 AT 1600 HRS	1600	2000
00	2400		14	ON LINE M.B.#23 AT 1630 HRS	1600	2000
00	0400		14	CHANGED BURNERS MB 21	2000	2400
00	0800		14	STOPPED SKIMMING MB 21 AT 2200 HRS CHANGED OVER TO MB 24 (6 HRS.)	2000	2400
00	1200	TUE.	15	BLOW SOOT M.B. 21, 23 & 24	0000	0400
00	1600		15	STOPPED SKIMMING MB#24 AT 0400	0400	0800
00	2000		15	START SKIMMING MB#23 AT 0530 HRS	0400	0800
00	2400		15	STOPPED SKIMMING MB 23 AT (1130 HRS.) AND CHANGED OVER TO MB 21 (6 HRS)	0800	1200
00	2400		15	STOPPED SKIMMING MB#21 AT 1730 HRS CHANGED OVER TO MB# 23 AT 1730 HRS	1600	2000
00	0400		15	CHANGED BURNERS MB 24	2000	2400
00	1200		15	STOPPED SKIMMING MB 23 AT 2330 HRS.	2000	2400
00	1600	WED.	16	BLOW SOOT M.B. 21 23 & 24	0000	0400
00	2400		16	OFF LINE MB# 23 AT (0700 HRS) BOTTOM BLOW DOWN (15 MINS)	0400	0800
00	2400		16	CHANGED BURNERS MB 21	2000	2400
00	0400	THU.	17	BLOW SOOT M.B. 21 & 24	0000	0400
00	0400		17	SLOW FIRING MB 23 AT 0900 HRS.	0800	1200

DAY	DATE		TIME		DAY	DATE
THU	17	ON LINE MB 23 (1700)	1600	2000	SAT.	26
THU	17	CHANGED BURNERS MB 24	2000	2400		26
FRI.	18	BLOW SOOT M.B. 21, 23 & 24	0000	0400		26
	18	CHANGED BURNERS MB 23	2000	2400		26
SAT.	19	BLOW SOOT M.B. 21, 23 & 24	0000	0400	SUN.	27
	19	OFF LINE MB 21 1030 HRS.	0800	1200	*	27
	19	BOTTOM BLOW DOWN MB 21 (15 MINS.)	0800	1200		27
	19	CHANGED BURNERS MB 24	2000	2400		27
SUN.	20	BLOW SOOT M.B. 23 & 24	0000	0400	MON.	28
	20	CHANGING OF WATCH * * *	1200	1600		28
	20	CHANGED BURNERS MB 23	2000	2400		28
MON.	21	BLOW SOOT MB. 23, 24	0000	0400		28
	21	START SLOW FIRING M.B. 21 AT 0430 HRS.	0400	0800	TUE.	29
	21	START SLOW FIRING M.B. 22 AT 1130 HRS	0800	1200	*	29
	21	START SKIMMING MB 23 AT 1330 HRS	1200	1600		29
	21	STOPPED SKIMMING M.B. 23 AT 1600 Hrs. COL M.B. 21 DRAIN,	1200	1600		20
	21	ON LINE M.B. 22 AT 2130 HRS	2000	2400	WED.	30
	21	CHANGED BURNERS M.B. 24	2000	2400		30
	21	SKIMMING MB. 23 AT 2200 HRS	2000	2400		30
TUE.	22	BLOW SOOT MB. 22, 23 & 24	0000	0400		30
	22	STOP SKIMMING MB 23 AT 0200 HRS	0000	0400		30
	22	SKIMMING M.B. 22 AT 2100 HRS	2000	2400		30
	22	CHANGED BURNERS M.B. 23	2000	2400		30
WED.	23	BLOW SOOT MB 22, 23 & 24	0000	0400		30
	23	STOP SKIMMING MB 22 AT 0300 HRS	0000	0400	THU.	31
	23	SKIMMING MB 22 AT 2000 HRS. (6 HRS.)	2000	2400		31
	22	CHANGED BURNERS M.B. 22	2000	2400		31
THU.	24	BLOW SOOT MB 22, 23 & 24	0000	0400		31
	24	STOP SKIMMING MB 22 AT 0200 HRS.	0000	0400	FRI.	01
	24	CHANGED BURNERS M.B. 24	2000	2400		01
FRI.	25	BLOW SOOT MB 22, 23 & 24	0000	0400		01
	25	CHANGED BURNERS MB 23	2000	2400		01
SAT.	26	NO SOOT BLOWING	0000	0400	SAT.	02
					*	02

TIME		DAY	DATE		TIME	
0	2000	SAT.	26	OFF LINE MB 24 AT 1230 HRS. LEAKING	1200	1600
0	2400		26	START SKIMMING MB 23 AT 1330 HRS	1200	1600
00	0400		26	STOPPED SKIMMING M.B. 23 & CHANGED OVER TO M.B. 22 AT 1930 HRS. (6 HRS.)	1600	2000
0	2400		26	STOPPED SKIMMING MB. 22 AT 2030 HRS CHANGED OVER TO MB. 23 AT 2030 HRS. (6 HRS)		
00	0400	SUN.	27	BLOW SOOT MB 22, 23	0000	0400
00	1200	*	27	CLOCK RETARDED 1 HOUR (2 O'CLOCK)	0000	0400
00	1200		27	STOP SKIMMING MB 23 AT 0230 HRS	0000	0400
0	2400		27	CHANGED BURNERS MB 23	2000	2400
00	0400	MON.	28	BLOW SOOT MB 22, 23	0000	0400
0	1600		28	START SLOW FIRING M.B. 21 AT 0440 HRS.	0400	0800
00	2400		28	ON LINE M.B. 21 AT 1630 HRS.	1600	2000
0	0400		28	CHANGED BURNERS MB 22	2000	2400
00	0800	TUE.	29	BLOW SOOT MB 21, 22 & 23	0000	0400
0	1200	*	29	CLOCK ADVANCE 1 HR. AT 0200 HRS.	0000	0400
0	1600		29	CHANGED BURNERS MB 23	2000	2400
00	1600		29	SKIMMING MB 22 (2200-0600) 8 HRS.	2000	2400
0	2400	WED.	30	BLOW SOOT MB. 22, 23 & 24	0000	0400
00	2400		30	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 23 AT 0600 HRS. (6 HRS)	0400	0800
0	2400		30	START SLOW FIRING M.B. 21 AT 1000 HRS	0800	1200
00	0400		30	STOPPED SKIMMING M.B. 23 AT 1200 HRS	0800	1200
00	0400		30	ON LINE M.B. 24 AT 1850 HRS.	1600	2000
0	2400		30	OFF LINE M.B. 21 AT 2030 HRS BOTTOM BLOW DOWN M.B. 21 15 MINS.	2000	2400
00	2400		30	CHANGED BURNERS M.B. 22	2000	2400
00	0400		30	SKIMMING MB 22 (2315-0715) 8 HRS.	2000	2400
00	0400	THU.	31	BLOW SOOT MB. 22, 23 & 24	0000	0400
00	2400		31	STOPPED SKIMMING M.B. 22 AT 0715 HRS.	0400	0800
00	2400		31	CHANGED BURNERS MB 23	2000	2400
00	0400		31	SKIMMING MB 22 AT 2130 HRS (4 HRS)	2000	2400
00	0400	FRI.	01	"NOVEMBER 2002" * * *		
0	2400		01	BLOW SOOT MB 22, 23 & 24	0000	0400
0	0400		01	STOP SKIMMING MB 22 AT 0130 HRS	0000	0400
00	2400		01	CHANGED BURNERS MB 24	2000	2400
00	0400	SAT.	02	BLOW SOOT MB 22, 23 & 24	0000	0400
		*	02	CLOCK RETARDED 1 HOUR (AT 2 O'CLOCK)	0000	0400

"NOVEMBER"

DAY	DATE		TIME		DAY	DATE
SAT	02	OFF LINE MB 22 (1130 HRS)	0800	1200	FRI	08
	02	SKIMMING MB 23 (2130 HRS) 5 HRS.	2000	2400	SAT.	09
	02	CHANGED BURNERS MB. 23	2000	2400	*	09
SUN.	03	BLOW SOOT MB 23 & 24	0000	0400		09
	03	STOP SKIMMING MB 23 AT 0200 HRS.	0000	0400		09
	03	AND CHANGED OVER TO MB 24 (5 HRS)	0000	0400		09
	03	STOPPED SKIMMING M.B. 24 AT 0730 HRS	0400	0800		09
	03	SKIMMING MB 23 (2020) 6 HRS	2000	2400		09
	03	CHANGED BURNERS MB 24	2000	2400	SUN.	10
MON.	04	BLOW SOOT MB 23 & 24	0000	0400		10
	04	STOPPED SKIMMING MB 22 AT 0220 HRS.	0000	0400		10
	04	START SLOW FIRING MB 22 (1000 HRS)	0800	1200	MON.	11
	04	ON LINE M.B. 22 AT 1900 HRS.	1600	2000		11
	04	SKIMMING MB 23 2100 HRS (6 HRS)	2000	2400		11
	04	CHANGED BURNER # 2 MB 22	2000	2400		11
	04	CHANGED BURNERS MB 23	2000	2400		11
TUE.	05	BLOW SOOT MB 22, 23 & 24	0000	0400		11
	05	STOPPED SKIMMING MB 23 AT (0300 HRS) AND CHANGED OVER TO MB 24	0000	0400		11
*	05	CLOCK ADVANCE 1-HR AT 0200 HRS	0100	0200	TUE.	12
	05	STOPPED SKIMMING M.B. 24 AT 0700 HRS	0400	0800		12
	05	CHANGED BURNERS MB 24	2000	2400	*	12
	05	SKIMMING MB 22 (2230) 6 HRS.	2000	2400		12
WED.	06	BLOW SOOT MB 22, 23 & 24	0000	0400		12
	06	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 23 AT 0430 HRS. (6-HRS)	0400	0800		12
	06	STOPPED SKIMMING MB 23 1030 HRS	0800	1200		12
	06	CHANGED BURNERS MB 22	2000	2400	WED.	13
	06	SKIMMING MB 22 (2230 HRS) 6 HRS.	2000	2400		13
THU.	07	BLOW SOOT MB 22, 23, 24	0000	0400		13
	07	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 24 AT 0430 HRS. (6-HR.)	0400	0800		13
	07	STOPPED SKIMMING MB 24 AT 1030 HRS	0800	1200		13
	07	CHANGED BURNERS MB 23	2000	2400	THU.	14
FRI.	08	BLOW SOOT MB 22, 23 & 24	0000	0400		14
	08	START SKIMMING MB 22 AT 1330 HRS	1200	1600		14
	08	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 23 AT 1930 HRS. (6-HRS.)	1600	2000		

(MC. LON TRANSFER TO NORTH LEAN)

TIME		DAY	DATE	DAWN NOVEMBER 10, 2002	TIME	
000	1200	FRI	08	CHANGED BURNERS MB 24	2000	2400
2000	2400	SAT.	09	BLOW SOOT MB 22, 23 & 24	0000	0400
000	2400	*	09	CLOCK RETARDED 1 HOUR (AT 2 O'CLOCK)	0000	0400
000	0400		09	STOPPED SKIMMING MB 23 AT (0130 HOUR) AND CHANGED OVER TO MB 24 (6 HRS.)	0000	0400
000	0400		09	STOPPED SKIMMING M.B. 24 AT 0730 HRS.	0400	0800
000	0400		09	OFF LINE MB 22 1015 HRS.	0800	1200
400	0800		09	BOTTOM BLOW DOWN 15 MINS (MB 22)	0800	1200
000	2400		09	CHANGED BURNERS MB 23	2000	2400
000	2400	SUN.	10	BLOW SOOT MB 23, 24	0000	0400
000	0400		10	CHANGED BURNERS MB 24	2000	2400
000	0400		10	SKIMMING MB 24 (2200) 6 HRS.	2000	2400
000	1200	MON.	11	BLOW SOOT MB 23, 24	0000	0400
00	2000		11	STOP SKIMMING MB 24 AT 0400 HRS. AND CHANGE OVER TO MB 23 6 HRS.	0000	0400
000	2400		11	STOPPED SKIMMING M.B. 23 AT 0745 HRS.	0400	0800
000	2400		11	START FIRING MB 22 1030 HRS	0800	1200
000	2400		11	ON LINE M.B. 22 AT 1830 HRS.	1600	2000
000	0400		11	CHANGED BURNERS MB 23	2000	2400
000	0400		11	SKIMMING MB 22 (2130) 4 HRS.	2000	2400
[illegible]	[illegible]	TUE.	12	BLOW SOOT MB 22, 23 & 24	0000	0400
[illegible]	[illegible]		12	STOPPED SKIMMING MB 22 AT 0130 AND CHANGED OVER TO MB 23 (4 HRS.)	0000	0400
000	2400	*	12	CLOCK ADVANCE 1 HOUR AT (2 O'CLOCK)	0000	0400
000	2400		12	STOPPED SKIMMING M.B. 23 & CHANGED OVER TO M.B. 24 AT 0630 HRS. (4 HRS.)	0400	0800
000	0400		12	STOPPED SKIMMING MB 24 (1030)	0800	1200
0400	0800		12	CHANGED BURNERS MB 24	2000	2400
800	1200		12	SKIMMING MB 22 (2130) 6 HRS.	2000	2400
000	2400	WED.	13	BLOW SOOT MB 22, 23 & 24	0000	0400
000	2400		13	STOPPED SKIMMING MB 22 AT 0330 HRS. AND CHANGED OVER TO MB 23 (6 HRS.)	0000	0400
000	0400		13	STOPPED SKIMMING MB 23 0930 .. CHANGED OVER TO MB 24 (3 HRS.)	0800	1200
400	0800		13	STOPPED SKIMMING MB 24 AT 1530 HRS.	1200	1600
000	20)		13	CHANGED BURNERS MB 22	2000	2400
000	2400	THU.	14	BLOW SOOT MB 22, 23 & 24	0000	0400
000	0400		14	CHANGED BURNERS MB 23	2000	2400
00	1600		14	SKIMMING MB 22 (2230) 4 HRS.	2000	2400
600	2000					

"NOVEMBER 2002"

DAY	DATE		TIME		DAY	DATE
FRI	15	BLOW SOOT MB 22, 23 & 24	0000	0400	WED	20
	15	STOPPED SKIMMING MB 22 AT 0230 AND CHANGED OVER TO MB 23 4 HRS.	0000	0400		20
	15	STOPPED SKIMMING M.B. 23 AT 0630 HRS.	0400	0800		20
	15	START FIRING MB 21 (1035 HRS.)	0800	1200		20
	15	STOPPED FIRING MB 21 AT 1500 HRS.	1200	1600	THU	21
	15	SKIMMING MB 22 (2030) 6 HRS	2000	2400		21
	15	CHANGED BURNERS MB 24	2000	2400		21
SAT	16	CLOCK RETARDED 1 HOUR AT (2 O'CLOCK)	0000	0400		21
	16	BLOW SOOT MB 22, 23 & 24	0000	0400		21
	16	STOPPED SKIMMING MB 22 AT 0230 HRS. AND CHANGED OVER TO MB 23 6 HRS.	0000	0400		21
	16	STOPPED SKIMMING M.B. 23 & CHANGED OVER TO M.B. 24 AT 0730 HRS. (6-HRS.)	0400	0800	FRI	22
	16	STOPPED SKIMMING MB 24 0900 HRS	0800	1200		22
	16	OFF LINE MB 22 (1115 HRS)	0800	1200		22
	16	BOTTOM BLOWDOWN MB 22 15 MINS.	0800	1200		22
	16	CHANGED BURNERS MB 23	2000	2400		22
	16	SKIMMING MB 23 (2100-0300) 6 HRS.	2000	2400	SAT	23
SUN	17	BLOW SOOT MB 23, 24	0000	0400		23
	17	STOPPED SKIMMING MB 23 AT 0300 HRS.	0000	0400	*	23
	17	START SKIMMING MB 24 AT 1840 HRS 10 HRS.	1600	2000		23
	17	CHANGED BURNER'S M.B. 24	2000	2400		23
MON	18	BLOW SOOT MB 23, 24	0000	0400		23
	18	STOPPED SKIMMING MB 24 AT (0440 HRS) AND CHANGED OVER TO MB (23 6 HRS.)	0400	0800		23
	18	STOPPED SKIMMING M.B. 23 AT 1040 HRS.	0800	1200		23
	18	START SLOW FIRING M.B. 22 AT 1030 HRS.	0800	1200		23
	18	ON LINE MB 22 AT 1800 HRS.	1600	200	SUN	24
	18	STOPPED SKIMMING [illegible] AT (1945 HRS)	1600	[illegible]		24
	18	CHANGED BURNER'S M.B. 23	2000	2400	MON	25
TUE	19	1 HR. FORWARD (0200 HRS.)	0000	0400		25
	19	BLOWSOOT MB 22. 23. 24	0000	0400		25
	19	SKIMMING MB 22 (1315 HRS.) 6 HRS.	1200	1600		25
	19	STOPPED SKIMMING MB 22 AT 1915 HRS AND CHANGED OVER TO MB 23 6 HRS.	1600	2000		25
	19	CHANGED BURNER'S M.B. 24	2000	2400		25
WED	20	STOPPED SKIMMING MB 23 0115 HRS. CHANGED OVER TO MB 24 6 HRS.	0000	0400		25
	20	BLOWSOOT MB 22. 23. 24	0000	0400		

	TIME		DAY	DATE		TIME	
	0000	0400	WED	20	STOPPED SKIMMING MB 24 AT 0715 HRS.	0400	0800
	0000	0400		20	START SKIMMING MB 22 AT 1940 HRS.	1600	2000
HRS.	0400	0800		20	CHANGED BURNER'S M.B. 23	2000	2400
	0800	1200		20	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 23 AT 2340 HRS. (4-HRS.)	2000	2400
	1200	1600	THU	21	BLOWSOOT MB 22. 23. 24	0000	0400
	2000	2400		21	STOPPED SKIMMING MB 23. CHANGED OVER TO MB 24 (0340) 4 HRS.	0000	0400
	2000	2400		21	STOPPED SKIMMING MB 24 AT 0745 HRS.	0400	0800
	0000	0400		21	START SKIMMING MB 22 AT 1845 HRS.	1600	2000
	0000	0400		21	CHANGED BURNER'S M.B. 22	2000	2400
	0000	0400		21	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 24 AT 2245 HRS. (4-HRS.)	2000	2400
ED RS.)	0400	0800	FRI	22	STOPPED SKIMMING MB 24 0245	0000	0400
HRS	0800	1200		22	BLOWSOOT MB 22. 23. 24	0000	0400
	0800	1200		22	START SKIMMING MB 22 (1300) 6 HRS.	1200	1600
HRS.	0800	1200		22	STOPPED SKIMMING MB 22 AT 1900 HRS AND CHANGED OVER TO MB 23 6 HRS	1600	2000
	2000	2400		22	CHANGED BURNER'S M.B. 24	2000	2400
RS.	2000	2400	SAT	23	STOPPED SKIMMING MB 23 (0100). CHANGED OVER TO MB 24 (6 HRS.)	0000	0400
	0000	0400		23	BLOWSOOT MB 22. 23. 24	0000	0400
	0000	0400	*	23	1 HOUR BACK (0200 HRS.)	0000	0400
	1600	2000		23	STOPPED SKIMMING MB 24 AT 0600 HRS. AND CHANGED OVER TO MB 23 (4 HRS.)	0400	0800
	2000	2400		23	STOPPED SKIMMING M.B. 23 & CHANGED OVER TO M.B. 24 AT 1000 HRS. (4-HRS.)	0800	1200
	0000	0400		23	OFF LINE M.B. 22 AT 1100 HRS. BOTTOM BLOW DOWN M.B. 22 (15 MINS.)	0800	1200
	0400	0800		23	STOPPED SKIMMING MB 24 AT 1900 HRS. AND CHANGED OVER TO MB 23 (5 HRS.)	1600	2000
S.	0800	1200		23	CHANGED BURNER'S M.B. 23	2000	2400
RS.	0800	1200		23	STOPPED SKIMMING M.B. 24 AT 2400 HRS.	2000	2400
	1600	2000	SUN	24	BLOWSOOT MB 23, 24	0000	0400
	[illegible]			24	CHANGED BURNER'S M.B. 24	2000	2400
	2000	2400	MON	25	START SKIMMING MB 23 (0010) 6 HRS.	0000	0400
	0000	0400		25	BLOW SOOT MB 23. 24	0000	0400
	0000	0400		25	STOPPED SKIMMING MB 23 AT 0610 HRS AND CHANGED OVER TO MB 24 6 HRS.	0400	0800
S-	1200	1600		25	SLOW FIRING MB 22 AT 0840 HRS	0800	1200
	1600	2000		25	STOPPED SKIMMING MB 24 (1210 HRS.)	1200	1600
	2000	2400		25	ON LINE MB 22 AT 1645 HRS.	1600	2000
	0000	0400		25	CHANGED BURNER'S M.B. 23	2000	2400
	0000	0400					

DAY	DATE		TIME		DAY	DATE
TUE	26	BLOWSOOT MB 22.23.24	0000	0400	SUN	01
*	26	1 HR. FORWARD (0200 HRS.)	0000	0400	MON	02
	26	SKIMMING MB 22 (0345) 8 HRS.	0000	0400		02
	26	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 23 AT 1145 HRS. (6-HRS.)	0800	1200		02
	26	STOPPED SKIMMING MB 23 AT (1745 HRS) AND CHANGED OVER TO MB 24 (6 HRS.)	1600	2000		02
	26	CHANGED BURNER'S M.B. 22	2000	2400		02
	26	STOPPED SKIMMING M.B. 24 & CHANGED OVER TO M.B. 22 AT 2345 HRS. (6-HRS.)	2000	2400		02
WED	27	BLOWSOOT MB 22.23.24	0000	0400		02
	27	STOPPED SKIMMING MB 22 AT 0415 HRS	0400	0800		02
	27	START SKIMMING MB 22 AT 1950 HRS	1600	2000	TUE	03
	27	CHANGED BURNER'S M.B. 24	2000	2400		03
THU	28	STOPPED SKIMMING MB 22 (0015) HRS. CHANGED OVER TO MB 23 6 HRS.	0000	0400		03
	28	BLOWSOOT MB 22.23.24	0000	0400		03
	28	STOPPED SKIMMING MB 23 AT 0615 HRS. AND CHANGED OVER TO MB 24 6 HRS.	0400	0800		03
	28	STOPPED SKIMMING MB 24 1215 HRS. CHANGED OVER TO MB 22 6 HRS.	1200	1600		03
	28	STOPPED SKIMMING MB 22 AT 1815 HRS. AND CHANGED OVER TO MB 23 6 HRS.	1600	2000	WED.	04
	28	CHANGED BURNER'S M.B. 23	2000	2400		04
FRI	29	STOPPED SKIMMING MB 23 0015 HRS. CHANGED OVER TO MB 24 6 HRS.	0000	0400		04
	29	BLOWSOOT MB 22.23.24	0000	0400		04
	29	STOPPED SKIMMING MB 24 AT 0615 HRS. AND CHANGED OVER TO MB 22 6 HRS.	0400	0800		04
	29	CHANGED BURNER'S M.B. 22	2000	2400	THU.	05
SAT	30	SKIMMING MB 22 (0045) 8 HRS.	0000	0400		05
	30	BLOWSOOT MB 22.23.24	0000	0400		05
*	30	1 HR. BACK (0200 HRS.)	0000	0400		05
	30	STOPPED SKIMMING MB 22 AT (0745 HRS.) AND CHANGED OVER TO MB (23 8 HRS.)	0400	0800		05
	30	OFF LINE M.B. 24 AT 0935 HRS. BOTTOM BLOW DOWN M.B. 24 (15 MINS.)	0800	1200		05
	30	CHANGED BURNER'S M.B. 23	2000	2400	FRI	06
	30	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 23 AT 2345 HRS.	2000	2400		
SUN.	01	"DECEMBER 2002"	*	*		06
	01	BLOWSOOT MB. 22 & 23	0000	0400		06
	01	STOPPED SKIMMING MB 23 0230 HRS	0000	0400		06
	01	START SKIMMING MB 22 AT 1745 HRS.	1600	2000	SAT.	07
	01	CHANGED BURNER'S M.B. 22	2000	2400		07
	01	TESTED ALL BURNER'S M.B. 24	2000	2400	*	07

"DECEMBER 2002"

TIME		DAY	DATE		TIME	
2000	2400	SUN	01	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 23 AT 2345 HRS. (6-HRS.)	2000	2400
0000	0400	MON	02	BLOW SOOT M.B. 22 & 23	0000	0400
0400	0800		02	STOPPED SKIMMING MB 23 AT 0545 AND CHANGED OVER TO MB 22 6 HRS.	0400	0800
0800	1200		02	START SLOW FIRING MB 24 AT 0630 HRS.	0400	0800
1600	2000		02	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 23 AT 1145 HRS. (6-HRS.)	0800	1200
2000	2400		02	ON LINE M.B. 24 at 1445 HRS.	1200	1600
2000	2400		02	STOPPED SKIMMING MB 23 AT 1745 HRS. AND CHANGED OVER TO MB 24 6 HRS	1600	2000
0000	0400		02	CHANGED BURNER'S M.B. 23	2000	2400
0400	0800		02	STOPPED SKIMMING M.B. 24 & CHANGED OVER TO M.B. 22 AT 2345 HRS. (6-HRS.)	2000	2400
1600	2000	TUE.	03	BLOW SOOT M.B. 22, 23 & 24	0000	0400
2000	2400		03	STOPPED SKIMMING MB 22 AT 0545 HRS. AND CHANGED OVER TO MB 24 6 HRS.	0400	0800
0000	0400		03	STOPPED SKIMMING M.B. 24 & CHANGED OVER TO M.B. 23 AT 1145 HRS. (6-HRS.)	0800	1200
0000	0400		03	STOPPED SKIMMING MB 23 AT 1745 HRS. AND CHANGED OVER TO MB 22 6 HRS.	1600	2000
0400	0800		03	CHANGED BURNER'S M.B. 22	2000	2400
1200	1600		03	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 24 AT 2345 HRS. (6-HRS)	2000	2400
1600	2000	WED.	04	BLOW SOOT M.B. 22, 23 & 24	0000	0400
2000	2400		04	STOPPED SKIMMING MB 24 AT 0545 AND CHANGED OVER TO MB 23 6 HRS.	0400	0800
0000	0400		04	STOPPED SKIMMING M.B. 23 AT 1145 HRS.	0800	1200
0000	0400		04	START SKIMMING MB 22 AT (1925 HRS) 6 HRS.	1600	2000
0400	0800		04	CHANGED BURNER'S M.B. 24	2000	2400
2000	2400	THU.	05	BLOW SOOT M.B. 22, 23 & 24	0000	0400
0000	0400		05	STOPPED SKIMMING M.B. 22 AT 0125 HRS CHANGED OVER M.B. 24 FOR 6 HRS	0000	0400
0000	0400		05	STOPPED SKIMMING MB 24 AT 0725 HRS AND CHANGED OVER TO MB 23 6 HRS.	0400	0800
0000	0400		05	STOPPED SKIMMING M.B. 23 AT 1325 HRS CHANGED OVER M.B. 22 FOR 8 HRS.	1200	1600
0400	0800		05	CHANGED BURNER M.B. 23	1200	1600
0800	1200		05	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 24 AT 2125 HRS. (4-HRS.)	2000	2400
2000	2400	FRI	06	BLOW SOOT M.B. 22, 23 & 24	0000	0400
2000	2400			STOPPED SKIMMING M.B. 24 AT 0125 HRS. CHANGED OVER TO M.B. 23 4 HRS.	0000	0400
*	*		06	STOPPED SKIMMING MB 23 AT 0525 HRS. AND CHANGE OVER TO MB 22 (8 HRS.)	0400	0800
0000	0400		06	STOPPED SKIMMING MB 22 AT 1800 HRS.	1600	2000
0000	0400		06	CHANGED BURNERS M.B. 24	2000	2400
1600	2000	SAT.	07	BLOW SOOT M.B. 22, 23 & 24	0000	0400
2000	2400		07	SKIMMING M.B. 22 AT 0215 HRS.	0000	0400
2000	2400	*	07	1-HR. BACK AT 0200 HRS.	0000	0400

DAY	DATE	"SLUG ARMADEC"	TIME		DAY	DA
SAT.	07	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 23 AT 0815 HRS. (6-HRS.)	0800	1200	SAT.	1
	07	OFF LINE M.B. #22 AT 1210 HRS.	1200	1600		1
	07	CHANGED BURNER'S M.B. 23 (OK)	2000	2400		1
	07	STOPPED SKIMMING M.B. 23 1430 HRS	1200	1600		1
SUN.	08	BLOW SOOT M.B. 23 & 24	0000	0400		1
	08	CHANGED BURNER'S M.B. 24	0800	1200	SUN.	1
	08	TESTED ALL BURNER'S M.B. 22	2000	2400	*	1
MON.	09	BLOW SOOT M.B. 23 & 24 @	0000	0400		1
	09	START SLOW FIRING M.B. 22 AT 03:00 HR	0000	0400	MON.	1
	09	ON LINE M.B. 22 AT 1100 HRS.	0800	1200		1
	09	CHANGED BURNER'S M.B. 23	2000	2400		1
TUE.	10	BLOW SOOT M.B. 22 = 23 = 24 @	0000	0400		1
	10	CLOCK ADVANCED (1 HR) AT 02:00 HRS.	0000	0400		1
	10	START SLOW FIRING M.B. 21 AT 1015 HRS. 1-MIN/HR.	0800	1200	TUE.	1
	10	CHANGED BURNER'S M.B. 24	2000	2400	*	1
WED.	11	BLOW SOOT M.B. 22 = 23 = 24 @	0000	0400		1
	11	OFF LINE M.B. 24 AT 0900 HRS. BOTTOM BLOW DOWN M.B. 24 AT 10 BAR TO 3 BAR.	0800	1200	WED.	1
	11	CHANGED BURNER'S M.B. 22	2000	2400		1
	11	ON LINE M.B. 21 AT 2000 HRS.	2000	2400	THU.	1
THU.	12	BLOW SOOT M.B. 21 = 22 = 23 @	0000	0400	BLACK OUT ST. THOMAS.	1
	12	START SKIMMING MB 21 AT 1800 HRS.	1600	2000	FRI.	2
	12	CHANGED BURNER M.B. 23	2000	2400		2
	12	STOPPED SKIMMING M.B. 21 & CHANGED OVER TO M.B. 22 AT 2300 HRS. (5-HRS.)	2000	2400		
FRI.	13	BLOW SOOT M.B. 22 = 23 = 21 @	0000	0400		2
	13	STOPPED SKIMMING M.B. 22 AT 0400 HRS. CHANGED OVER M.B. 23 (5 HRS.)	0400	0400		2
	13	STOPPED SKIMMING M.B. 23 AT 0900 HRS.	0800	1200	SAT.	2
	13	SKIMMING M.B. 22 AT 14:00 HRS. (7 HRS.)	1200	1600	*	2
	13	CHANGED BURNER'S M.B. 21	2000	2400		
	13	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 23 AT 2100 HRS. (7-HRS.)	2000	2400		2
SAT.	14	BLOW SOOT M.B. 21 = 22 = 23	0000	0400		2
	14	CLOCK RETARDED (1 HR) AT 02:00 HRS.	0000	0400		
	14	STOPPED SKIMMING M.B. 23 = 0400 HRS.	0000	0400		2
	14	OFF LINE M.B. 23 AT 12:45 HRS.	1200	1600		

"DECEMBER 2002"

TIME		DAY	DATE		TIME	
800	1200	SAT.	14	SKIMMING M.B. 22 AT 1430 HRS (3 HRS)	1200	1600
200	1600		14	STOPPED SKIMMING MB 22 AT (1730 HRS)	1600	2000
200	2400		14	CHANGED OVER TO MB 21 (3 HRS)	1600	2000
200	1600		14	STOPPED SKIMMING MB 21 AT 1900 HRS.	1600	2000
000	0400		14	CHANGED BURNER M.B. 22	2000	2400
800	1200	SUN.	15	BLOW SOOT M.B. 21 = 22 @	0000	0400
000	2400	*	15	CHANGING OF WATCH * * *	1200	1600
000	0400		15	CHANGED BURNERS MB 21	2000	2400
000	0400	MON.	16	BLOW SOOT M.B. 21 & 22	0000	0400
800	1200		16	TESTED ALL BURNERS M.B. 23	0000	0400
000	2400		16	START SLOW FIRING MB 23 AT 0800 HRS	0800	1200
000	0400		16	ON LINE M.B. 23 AT 1600 HRS.	1600	2000
000	0400		16	CHANGED BURNERS MB 22	2000	2400
800	1200	TUE.	17	BLOW SOOT M.B. 21, 22 & 23	0000	0400
000	2400	*	17	CLOCK ADVANCE 1-HR. AT 0200 HRS.	0000	0400
000	0400		17	CHANGED BURNERS MB 21	2000	2400
0800	1200	WED.	18	BLOW SOOT M.B. 21, 22 & 23	0000	0400
2000	2400		18	CHANGED BURNERS MB 23	2000	2400
2000	2400	THU.	19	BLOW SOOT M.B. 21, 22 & 23	0000	0400
000	0400	BLACK OUT ST. THOMAS.	19	CHANGED BURNERS MB 22	2000	2400
600	2000	FRI.	20	BLOW SOOT M.B. 21, 22 & 23	0000	0400
000	2400		20	START SKIMMING MB 21 AT 0900 HRS. 7 HRS.	0800	1200
2000	2400		20	STOPPED SKIMMING M.B. 21 AT 1600 HRS Changed over to M.B. 22 (7 HRS.)	1200	1600
000	0400		20	CHANGED BURNERS MB 23	2000	2400
400	0400		20	STOPPED SKIMMING MB 22 AT 2300 HRS. AND CHANGED OVER TO MB 23 (7 HRS)	2000	2400
800	1200	SAT.	21	BLOW SOOT M.B. 21, 22 & 23	0000	0400
200	1600	*	21	CLOCK RETARDED 1-HR. AT 0200 HRS.	0000	0400
000	2400		21	STOPPED SKIMMING M.B. 23 AT 0600 HRS	0400	0800
2000	2400		21	START SKIMMING MB 22 AT 1100 HRS.	0800	1200
000	0400		21	STOPPED SKIMMING M.B. 22 AT 1300 HRS	1200	1600
000	0400		21	SKIMMING M.B. 22 AT 17:00 HRS. (7 HRS.)	1600	2000
000	0400		21	CHANGED BURNERS MB 21	2000	2400
200	1600		21	STOPPED SKIMMING MB 22 AT (2400 HRS) AND CHANGED OVER to MB (21 3 HRS.)	2000	2400

DECEMBER. 2002

DAY	DATE		TIME	
SUN.	22	BLOW SOOT M.B. 21, 22 & 23	0000	0400
	22	STOPPED SKIMMING M.B. 21 AT 0300 HRS.	0000	0400
	22.	OFF LINE M.B. 23 AT (05:50 HRS.)	0400	0800
	22	CHANGED BURNERS MB 22	2000	2400
	22	START SLOW FIRING MB 23 AT (2300 HRS)	2000	2400
MON.	23	BLOW SOOT M.B. 21 & 22	0000	0400
	23	ON LINE M.B. 23 AT (06:50 HRS.)	0400	0800
	23	START SKIMMING MB 23 AT (0940 HRS 6 HRS)	0800	1200
	23	STOPPED SKIMMING M.B. 23 & CHANGED OVER TO M.B. 22 AT 1540 HRS. (6-HRS)	1200	1600
	23	CHANGED BURNERS MB 21	2000	2400
	23	STOPPED SKIMMING MB 22 AT 2140 HRS AND CHANGED OVER TO MB 21 (6 HRS.)	2000	2400
TUE.	24	BLOW SOOT M.B. 21, 22 & 23	0000	0400
*	24	CLOCK ADVANCE 1-HR. AT 0200 HRS.	0000	0400
	24	STOPPED SKIMMING M.B. 21 AT 0340 HRS.	0000	0400
	24	START SKIMMING MB 22 AT (1020 HRS.) 6 HRS	0800	1200
	24	STOPPED SKIMMING M.B. 22 AT 16:20 HRS. Changed over M.B. 21 (6 HRS.)	1600	2000
	24	STOPPED SKIMMING MB 21 AT 2220 HRS AND CHANGED OVER TO MB 23 6 HRS.	2000	2400
	24	CHANGED BURNERS MB 23	2000	2400
WED.	25	BLOW SOOT M.B. 21, 22 & 23	0000	0400
	25.	STOPPED SKIMMING M.B. 23 AT 04:20 HRS.	0400	0800
	25	CHANGED BURNERS MB 22	2000	2400
THU.	26	BLOW SOOT M.B. 21, 22 & 23	0000	0400
	26	CHANGED BURNERS MB 21	2000	2400
FRI.	27	BLOW SOOT M.B. 21, 22 & 23	0000	0400
	27	START SLOW FIRING M.B. 24 3 MIN/10 MINS.	0000	0400
	27	START SKIMMING MB 22 AT (1120 HRS) 4 HRS	0800	1200
	27	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 21 AT 1520 HRS. (4 HRS.)	1200	1600
	27	STOPPED SKIMMING M.B. 21 AT 19:20 HRS. Changed over M.B. 23 (4 HRS.).	1600	2000
	27	ON Line M.B. 24 AT 2000 HRS.	2000	2400
	27	CHANGED BURNERS MB 22	2000	2400
	27	STOPPED SKIMMING MB 23 AT (2320 HRS)	2000	2400
SAT.	28	BLOW SOOT M.B. 21, 22, 23 & 24	0000	0400
	28	CLOCK RETARDED 1 HR AT 0200 HRS	0000	0400
	28	OFF LINE MB 23 AT 1020 HRS.	0800	1200
	28	BOTTOM BLOW DOWN 10 MINS.	0800	1200

DAY	DATE
SAT.	28
SUN.	29
	29
	29
	29
	29
	29
MON.	30
	30
TUE.	31
*	31
	31
	31
	31
	31

TIME		DAY	DATE		TIME	
000	0400	SAT.	28	CHANGED BURNERS MB 21	2000	2400
000	0400	SUN.	29	BLOW SOOT M.B. 21, 22 & 24	0000	0400
400	0800		29	START SKIMMING MB 22 AT (1000 HRS) 4 HRS.	0800	1200
000	2400		29	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 21 AT 1400 HRS. (4-HRS)	1200	1600
000	2400		29	STOPPED SKIMMING M.B. 21 AT 1800 HRS. Changed over M.B. 24 (4 HRS.)	1600	2000
000	0400		29	CHANGED BURNERS MB 24	2000	2400
400	0800		29	STOPPED SKIMMING MB 24 AT 2200 HRS.	2000	2400
800	1200	MON.	30	BLOW SOOT M.B. 21, 22 & 24	0000	0400
1200	1600		30	CHANGED BURNERS MB 22	2000	2400
000	2400	TUE.	31	BLOW SOOT M.B 21, 22 & 24	0000	0400
000	2400	*	31	CLOCK ADVANCE 1-HR. AT 0200 HRS.	0000	0400
000	0400		31	START SKIMMING MB 22 AT 0900 HRS.	0800	1200
000	0400		31	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 21 AT 1500 HRS. (6-HRS.)	1200	1600
000	0400		31	STOPPED SKIMMING MB 21 AT 2100 HRS	2000	2400
800	1200		31	CHANGED BURNERS. MB 21	2000	2400
600	2000					
000	2400					
000	2400					
000	0400					
400	0800					
000	2400					
000	0400					
2000	2400					
000	0400					
000	0400					
800	1200					
200	1600					
600	2000					
000	2400					
000	2400					
000	2400					
000	0400					
000	0400					
800	1200					
800	1200					

"HAPPY NEW YEAR 2003"

638

http//www.sight/glass.com.ph

BOILER	DATE		REMARKS	BOILER	I
				MB-23	2
				M.B. 22	3
				MB. 23	3
				M.B. 21	4
				M.B. 24	4
				MB 21	[illegible]
				M.B. 23	[illegible]
				MB 21	1
				M.B. 24	1
				MB 21	DE
				M.B. 23	1:

HTTP//WWW.SIGHT/GLASS.COM.PH 289

2002

REMARKS	BOILER	DATE	S/S NORWAY ***	REMARKS	KS
	MB-23	2-15-02	STARBOARD SIDE	LEAKING	ING
	M.B. 22	3-17-02	STARBOARD SIDE	LEAKING	NG
	MB. 23	3-23-02	PORT SIDE	LEAKING	NG
	M.B. 21	4-03-02	STARBOARD SIDE	LEAKING	NG
	M.B. 24	4-22-02	PORT SIDE	LEAKING	NG
	MB 21	7-08-02	PORT SIDE	DIRTY	ng
	MB. 23	7-25-02	STARBOARD SIDE	LEAKING	NG
	MB 21	11-18-02	STARBOARD SIDE	DIRTY	ng
	MB 24	12-07-02	STARBOARD SIDE	LEAKING	NG
	MB 21	DEC. 24-02	PORT SIDE	LEAKING	—
	M.B. 23	12-24-02	PORT SIDE @@@	LEAKING	
					NG
					@

http//www.sight/glass.com.ph

2001

DATE	BOILER	CHANGING OF DRUM SIGHT GLS.	REMARKS	BOILER
				M.B. 2
JAN. 04,01	M/B 22	PORTSIDE	LEAKING	M.B. 22
JAN 30,01	M.B. 23	STBD	—"—	M.B. 2
FEB. 01.01	M.B. 21	PORT SIDE	Leaking	M.B. 2
FEB. 04.01	M.B. 21	STARBOARD SIDE	LEAKING	M.B. 2
FEB 10.01	M.B. 24	PORT SIDE	LEAKING	M.B. 22
FEB. 15.01	M.B. 22.	STARBOARD SIDE	LEAKING	M.B. 2
FEB. 16.01	M.B. 23	PORT SIDE	DIRTY	M.B. 23
MAR 01-01	M.B. 23	PORT SIDE	DIRTY	MB 2
MAR. 11.01	M.B. 24	STARBOARD SIDE	Leaking	MB 2
MAR. 22.01	M.B. 22.	PORT SIDE	LEAKING	MB 21
MARCH 30.01	M.B. 22	STARBOARD SIDE	LEAKING	M.B. 23
APRIL 08.01	M.B. 21	STARBOARD. SIDE	DIRTY	* "
APRIL 23,01	M.B. 23	STARBOARD SIDE	LEAKING.	
APRIL 27,01	M.B. 21	PORT SIDE	LEAKING	
MAY 09.01	M.B. 24	PORT SIDE	LEAKING	
MAY 10.01	M.B. 22	PORT SIDE	LEAKING	
MAY 23.01	M.B. 24	STARBOARD SIDE	DIRTY	
June 28-01	M.B. 22.	PORT SIDE	LEAKING	
June 28,01	M.B. 21	STARBOARD SIDE	LEAKING.	
JULY 09.01	M.B. 23	STARBOARD SIDE	leaking	
JULY 17.01	M.B. 24	PORT SIDE	leaking	
Aug. 2.01	M.B. 22	STARBOARD SIDE	Leaking	
Aug 7,01	MB 21	PORTSIDE	DIRTY	
Aug. 12-01	M.B. 22	PORTSIDE	Leaking	
NOV. 30-01	M.B. 22	PORT SIDE	Leaking	
JAN. 05-02	M.B. 23	PORT SIDE	LEAKING	
JAN-07-02	MB #21	STARBOARD SIDE	LEAKING	
FEB 01.02	M.B. 22	PORT SIDE	LEAKING.	
* " *	* " *	* — o — *	* " *	

BOILER #	DATE	CHANGING OF DRUM SIGHT GLASS	REMARKS
M.B. 23	27 Aug 00	STARBOARD SIDE	LEAKING
M.B. 22	31 Aug. 00	PORTSIDE	LEAKING
M.B. 23	06 SEPT. 00	PORT SIDE	LEAKING
M.B. 21	06 SEPT. 00	PORT SIDE	LEAKING
M.B. 22	15 Sept. 00	STARBOARD SIDE	LEAKING
M.B. 23	18 Sept. 200	STARBOARD SIDE	Leaking
M.B. 24	28 Sept. 00	STARBOARD SIDE	LEAKING
M.B. 22	15 Oct. 00	Port side	Leaking
MB 23	30 NOV. 00	PORTSIDE	LEAKING
MB 22	23 DEC. 00	STBD.	— " —
MB 21	28 DEC. 00	STB.	do
M.B. 23	30 JAN. 2001	STARBOARD SIDE	LEAKING
* // *	* — *	* — * * — *	— // —

2000

www.sight/glass.com

BOILER #	DATE	CHANGING OF DRUM SIGHT GLASS	REMARK
M.B. 24	NOV. 14 '99	PORTSIDE.	LEAKING
MB 21	DEC. 13 '99	PORTSIDE	"
M.B. 22	JAN 05 00	PORTSIDE	LEAKING
MB. 24	JAN 15,00	STB.	DIRTY GL
M.B. 22	JAN 15,00	STB.	LEAKING
M.B. 23	JAN. 17,00	PORT SIDE	LEAKING
M.B. 23	MARCH 3,'00	STBSIDE	—"—
M.B 23	03-28-00	Port Side	DIRTY GLS.
M.B. 24	~~APR.~~ 03-00	(Leaking) PORTSIDE	Leaking #
M.B. 24	04-09-00	Port Side	Leaking#
M.B. 23	04-12-00	STB. SIDE	Leaking
M.B. 24	APRIL 13.00	STARBOARD SIDE	Leaking
M.B. 22	April 24,00	STARBOARD SIDE	DIRTY GLS.
M.B. 21	MAY 05.00	Leaking (PORT SIDE)	Leaking
M.B. 22	MAY 09/00	STB.	DIRTY
M.B. 22	MAY 11,00	PORTSIDE	Leaking.
M.B. 23	MAY 19.00	Leaking STARBOARD SIDE.	Leaking
M.B. 21	MAY 31 00	STARBOARD SIDE	Leaking
M.B. 23	JUNE 03.00	PORTSIDE	Leaking
M.B. 21	JUNE 17,00	PORT SIDE	Leaking
M.B. 22	June 19'00	Port Side	Leaking
M.B. 24	June 29.00	Port Side	Leaking
M.B. 22	July 03'00	STBD. SIDE	Leaking
M.B. 21	July 17,'00	STBD. SIDE	Leaking
M.B. 24	July 19'00	STB. SIDE	DIRTY
M.B. 21	JULY 24.00	PORTSIDE	LEAKING
M.B. 22	JULY 27.00	PORTSIDE	LEAKING.
M.B. 24	July 27,00	PORTSIDE	LEAKING
M.B. 22	Aug. 11.00	STBD. SIDE	LEAKING
M.B. 24	Aug. 14.00	~~STARBOARD~~ SIDE PORT	LEAKING
M.B. 24	Aug 20.00	STBD. SIDE.	Leaking
M.B. 23	Aug. 21.00	PORT SIDE.	DIRTY

DATE
M.B 24
M.B 22
MB 21
~~M.B. 21~~
M/B 22
M.B. 23
M.B. 22.
M.B 23
M.B. 24
MB 22
M.B 22
M.B. 24
M.B. 21
M.B. 21
M.B. 23
M.B. 24
M.B. 22.
M.B. 24
M.B. 24
M.B. 23
M. B. 21
M.B. 23
M.B. 22
M.B. 24
M.B. 21
M.B. 24
M.B. 21

DATE	CHANGED OF GLYCERINE OF F.O TRANSMITTER.	
M.B 24	SEPT. 01, 98	
M.B 22	SEPT. 12 '98	M.B 22 / JUNE 6, 02
M.B 21	NOV. 24 '98	
~~M.B. 24~~	*	
M/B 22	DEC. 23, '98	
M.B. 23	JAN. 8 '99	
M.B. 22.	Aug. 10. 99	
M.B 23	Aug 11, 99	
M.B. 24	15 SEPT, 99	
M.B 22	25 OCT, '99	
M.B 22	04 FEB 2000	
M.B. 24	07 FEBRUARY 2000	
M.B. 21	19 FEBRUARY 2000	
M.B. 21	21 FEBRUARY 2000	
M.B. 23	APRIL 29.00	
M.B. 24	MAY 20.00	
M.B. 22.	MAY 22.00	
M.B. 24	AUG. 23.00	
M.B. 24	14 NOV. 00	
M.B. 23	28 NOV. 00	
M.B. 21	05 DEC. 00	
M.B. 23	08 DEC. 00	
M.B. 22	13 DEC. 00	
M.B. 24	23 JAN. 2001	
M.B. 21	01 JULY 2001	
M.B. 24	18 JULY 2001	
M.B. 21	DEC. 2001	

ADJUSTMENT OF IGNITERS

BOILER NO.	21	22	23	24
1	350 MM	370	380	365
2	372	370	370	375
3	365	370	373	340
4	400	375 355	340	375
5	380	365	365	365

#NORWAY#

PHONE # AFT WORKSHOP - 41276

PHONE # FWD. PIPE SHOP. - 41273

CENTRAL STORE-FWD FUCK YOU HANSEN - 41261 - 62 TOOL STORE

DECK & Engine MESS = ~~[illegible]~~ TEL # 41642 FAX #

PHONE # SAFETY OFFICER - 41157

PHONE # SECURITY OFFICER - 41155

PHONE # EMERGENCY - 911

PHONE # BRIDGE - 1111 / 1122

PHONE # INFORMATION — 101

HOSPITAL — 102

RADIO ROOM — 103

10-7-00
10-14-00
10-21-00
10-28-00
11-04-00
11-11-00
11-18-00
11-25-00
12-02-00
12-09-00
12-16-00
12-23-00
12-30-00
1-06-01
1-13-01
1-20-01
1-27-01
CREW CHECK
2-03-01
2-10-01
2-17-01
2-24-01
3-3-01
3-10-01
3-17-01
3-24-01
3-31-01

4-7-01
SUN 4-15-01
SUN 4-22-01
SUN 4-29-01 CREW CHECK
SU 5-6-01
5-13-01
5-20-01
5-27-01
6-3-01
6-10-01
6-17-01
6-24-01
7-01-01
7-8-01
7-15-01
7-22-01
CREW CHECK 7-29-01
8-5-01
8-12-01
8-19-01
8-26-01
9-2-01
9-9-01
9-16-01
9-23-01
9-30-01
10-7-01
BINGO

10-19-01
10-21-01
10-28-01
11-4-01
11-11-01
11-18-01
11-25-01
12-2-01
12-9-01
12-16-01
12-23-01
12-30-01
1-6-02
1-13-02
1-20-02
1-27-02
2-3-02
2-10-02
2-17-02
2-24-02
3-3-02
3-10-02
CREW CHECK
3-17-02
3-24-02
3-31-02
4-7-02
4-14-02
4-21-02
4-28-02
5-05-02
5-12-02
5-19-02
5-26-02

8-04-02
8-11-02
8-18-02
8-25-02
9-01-02
9-08-02
9-15-02
9-22-02
9-29-02
10-06-02
10-13-02
10-20-02
10-27-02
11-03-02
11-10-02
11-17-02
11-24-02

6-02-02 CREW
6-09-02
6-16-02
6-23-02
6-30-02
7-07-02
7-14-02
7-21-02
7-28-02

2003
1-05-03
1-12-03
1-19-03
1-26-03
2-02-03
2-09-03
2-16-03
2-23-03
3-02-03
3-09-03
3-16-03
3-23-03
3-30-03
4-06-03
4-13-03
4-20-03
4-27-03
5-04-03
5-11-03
5-18-03
5-25-03
5-01-03
6-08-03
6-15-03
6-22-03
6-29-03
7-06-03
7-13-03
7-20-03
7-27-03
8-03-03
8-10-03
8-17-03
8-24-03
8-31-03
9-07-03
9-14-03
9-21-03
9-28-03
10-05-03
10-12-03
10-19-03
10-26-03
11-02-03
11-09-03
11-16-03
11-23-03
11-30-03
12-07-03
12-14-03
12-21-03
12-28-03

CR 2255

24232122