

DOCKET NO. SA-228

EXHIBIT NO. 17I

NATIONAL TRANSPORTATION SAFETY BOARD
WASHINGTON, D.C.

**EFFECT OF CELL STATE-OF-CHARGE ON OUTCOME OF INTERNAL
CELL FAULTS: PRELIMINARY REPORT**

(BY: E^xPONENT FAILURE ANALYSIS ASSOCIATES)

Exponent[®]

Failure Analysis Associates[®]

Effect of Cell State-of-Charge on Outcome of Internal Cell Faults: Preliminary Report

**Marcus Megerle
Ashley Kelley
Celina Mikolajczak**

August 6, 2004

Purpose of Testing



- **Examine the effect of cell state-of-charge (SOC) on the outcome of a low impedance internal cell fault**
- **SOC is the charge level of a battery cell divided by its charge capacity**
 - **The higher the SOC, the more energy available for release by an internal cell fault for comparable capacity cells. Higher energy release increases the probability of severe outcomes:**
 - **Fire**
 - **Energetic disassembly**
 - **For a given cell, the nature of the internal cell fault will determine the initial rate of energy release and potentially the severity of outcome**

Purpose of Testing (cont)

- **An internal cell fault could result from several causes, including:**
 - **Mechanical damage**
 - **External overheating**
 - **Overcharging or other charging anomalies**
 - **Charge cycling a cell with a manufacturing defect**


General Test Methodology

- Induce low impedance internal cell fault in controlled and repeatable manner
 - **Crush cell with arbor press***
 - Cell crush represents severe abuse conditions resulting in
 - Multiple low impedance shorts
 - Potential for rapid energy release
 - Provides a method to explore cell behavior during high discharge rate internal cell faults



Test Setup and Instrumentation

- Cell temperature measurements
 - Thermocouples on cell surface near crush zone
 - Infrared (IR) camera measures cell temperatures (surface painted white to allow accurate readings)
- IR data correlates to localized thermocouple measurements



Crush Profile

- **To initiate a severe internal cell fault**
 - **Crush must be aggressive enough to create low impedance shorting within cell**
 - **Goal is to induce an “internal short” condition leading to thermal runaway**
 - **Cell heating (temperature rises to $>100\text{ }^{\circ}\text{C}$)**
 - **Rise in internal pressure**
 - **Crush must not be so aggressive that it cracks the cell case**
 - **A case crack would act as a secondary cell vent**
 - **A case crack would reduce severity of outcome**
 - **Tests where the case cracks during crushing should not be directly compared to tests where case integrity has been maintained**

Crush Profile

- **Cell designs vary between manufacturers and brands**
 - Thickness of case wall
 - Ductility of case material
 - Rigidity of cell windings (“jelly roll”)
- **Preliminary testing showed**
 - Any single crush profile (force or depth) has limitations
 - Might induce low impedance shorts in cells by some manufacturers, while not inducing them in others.
 - Might induce low impedance shorts in all cells, but also cause case cracks with a particular cell design


Crush Profile

- **Preliminary testing showed**
 - **Crush profile can be tailored on a per brand or manufacturer basis to induce internal short by causing low impedance shorting with cracking the case**
 - **Increase crush aggressiveness until internal short achieved**
 - **Stop just short of causing case cracking**
 - **If internal short not achievable without also causing case cracking, try a multi-pulse crush**

Crush Profile

- **Crush tests that consistently achieve a low impedance cell fault have the following advantages**
 - **Allow direct comparison of different test cell brands or manufacturers**
 - **Allow for varying states-of-charge and difference capacities**
 - **Allow for estimating the performance of other lithium-ion cells with similar energy densities and technologies**

Crush Profile Determination



Note: An energetic outcome includes fire or energetic disassembly.

Cells Used in Testing

- State of the art (at the time of testing) 18650 style cells were obtained from three manufacturers
- 5 Cells per manufacturer were measured to verify cell capacity

Manufacturer Identification Color Code	Nominal Rated Capacity	Measured Capacity
A (Orange)	2.10 Ah	2.16 Ah \pm 1.5%
B (Green)	2.20 Ah	2.16 Ah \pm 2.0%
C (Blue)	2.15 Ah	2.15 Ah \pm 1.5%

Manufacturer Cell Capacity Evaluation

- Capacity variation determined before discharging to selected SOC
 - 5 cells per manufacturer were charged to 4.2 V and discharged through a calibrated resistor to 3.0 V while recording voltage, current, temperature, and time
 - Nominal capacities were within 3% of manufacturer specifications
 - Cell-to-cell capacity within brand varied 3-4%
- The SOC was set by discharging at 0.75 C
 - The 0.75 C rate was calculated using the specified cell capacities
 - 1 C is the constant discharge current that drains the nominal cell capacity in 60 min.
 - 0.75 C drains a fully charged cell in 80 min.

Setting SOC

- Nominal capacities for the three manufacturers are 2.10, 2.15, and 2.20 Ah
- Charging to 4.2 V (100% SOC)
- Discharging from 100% SOC with a constant 0.75 C across a dynamic load for a pre-determined period of time to reach lower SOC's


SOC [%]	Discharge time [min]
100 → 100	0
100 → 70	24.0
100 → 50	40.0
100 → 40	48.0
100 → 30	56.0

Observed Crush Outcomes


- **Observed crush outcomes have been classified into four categories, listed in decreasing order of severity**
 - **Fire: a “Severe” outcome**
 - **Energetic Disassembly: a “Severe” outcome**
 - **Case Rupture: a “Moderate” outcome**
 - **Internal short: a “Minimum” outcome**
- **Characterization is based on the most severe result observed:**
 - **Though an internal short condition was induced in all cells, a particular test was labeled “internal short” only when it did not exhibit any of the other outcomes.**
 - **Though the incidence of fire is sometimes accompanied by an energetic disassembly, all tests that resulted in fire were included only in the “Fire” category**

Fire Outcome


- **Coincident with crush action**
 - Appearance of flames
 - “Pop” or “hissing” sound
 - Cell may or may not disassemble or rupture
 - Rapid temperature rise immediately upon crush, on the order of 100 °C per second



Fire with Case Rupture





Fire with Cell Venting




Fire with Energetic Disassembly

Fire Outcome




Example 1: 70% SOC, early stage (left), later stage (right)



Example 2: 70% SOC, early stage (left), later stage (right)



Fire Outcome




Thermocouple Data for nine 70% SOC cells

Energetic Disassembly Outcome


- **Coincident with crush:**
 - Loud “Pop” sound
 - Cell cap may be projected
 - Significant portion (~ 1/3 to 1/2) of jellyroll may be ejected
 - Local temperature rise similar to fire outcome for a short period
 - Temperature rise of remaining jellyroll similar to internal short



Energetic Disassembly Outcome




Example 1: 70% SOC, initial stage (left), ejection (right)



Example 2: 70% SOC, ejection (left), later stage (right)


Energetic Disassembly Outcome




Thermocouple Data for three 70% SOC & one 100% SOC cells

Case Rupture Outcome


- **Coincident with crush:**
 - Loud “Pop” sound
 - Brief release of hot gases
 - Case ruptures along the side (fish-mouth opening created)
 - Bulk of jellyroll remains in place
 - Portions of exposed jellyroll windings expelled
 - Cap remains in place, vent activates
 - Case temperature maximum and rise rate similar to internal short outcome
- **Case ruptures caused by overpressure during the internal short**



Case Rupture Outcome




Example 1: 70% SOC, early stage (left), later stage (right)



Example 2: 50% SOC, early stage (left), later stage (right)


Case Rupture Outcome





Thermocouple Data for one 50% SOC & four 70% SOC cells

Internal Short Outcome



- **Coincident with crush:**
 - Soft or inaudible “pop” sound (vents activating)
 - Some designs contain up to three stages of vents
- **After crush**
 - Cell heating
 - To $>100\text{ }^{\circ}\text{C}$, at a rate of approximately $70\text{ }^{\circ}\text{C/min}$
 - Electrolyte can be released through vent



Internal Short Outcome




Example 1: 70% SOC, early stage (left), peak heating (right)




Example 2: 40% SOC, early stage (left), peak heating (right)

Internal Short Outcome



50% SOC Thermocouple Data

Internal Short Outcome



40% SOC Thermocouple Data

Raw Data in Order of Testing

Fire				XXX (3) XXXXX (5) XXXX (4)		xxxxxxx (6) xxxx (4)
Energetic Disassembly				XXXX (4) xx (2) X (1)		x (1)
Case Rupture		X (1)		XXX(3)		
Internal Short	XXXXXXXXXX (9) XXXXXCC (7) xxxx (4) XXCXXCXXCX (10)	XXXXXCXXX (9) XXCXXXCX (8) xxx (3) CXXXXXXXX (8)		X (1) CCCC (4) x (1) C (1)		xxc (3)
High impedance internal short Temperature Rise < 70 C	xc (2)	cxxxxxx (6)		cxxcxx (6)		cxxc (4)
SOC	40%	50%		70%		100%

'X' denotes individual crush test w/o case crack

'C' denotes individual crush test with case crack

Bold face denotes refined crush method

Italic/lower case denote preliminary crush method

Refined Data

- Set aside results of tests that do not meet criteria for a low impedance internal short or where the case cracked by the mechanical crushing and not from internal pressure


Fire			XXX (3) XXXXX (5) XXXX (4)
Energetic Disassembly			XXXX (4) X (1)
Case Rupture		X (1)	XXX(3)
Internal Short	XXXXXXXXXX (9) XXXXXX (5) XXXXXXXXXX (7)	XXXXXXXXXX (8) XXXXXXX (6) XXXXXXXXXX (7)	X (1)
SOC	40%	50%	70%

Discussion of Crush Results


- **At 100% SOC, a refined crush would typically produce a severe outcome using a refined test method.**
- **At 70% SOC, a refined crush resulted in severe outcomes for a majority of tests for each brand.**
- **At 50% SOC, all tests but one resulted in a minimum outcome. The one test resulted in a moderate outcome (case rupture).**
- **At 40% SOC, all of the tests resulted in a minimum outcome.**

Crush Outcome Trends


■ Minimum ■ Moderate ■ Severe



40% SOC
21 Refined Tests



50% SOC
22 Refined Tests



70% SOC
21 Refined Tests

Preliminary Conclusions

- The refined crush profile method was found to accommodate differences in “cell design” between manufacturers.
- The severity of crush outcome is strongly affected by state of charge. No severe or moderate outcomes were observed during any test of a cell with 40% SOC.
- The severity of crush outcome was not significantly affected by which company manufactured the cell.